


SIEMENS



SINAMICS

Low-voltage SINAMICS G120C converters

Built-in devices, frame sizes AA ... C

Compact Operating Instructions

Edition

07/2015

siemens.com

SIEMENS

SINAMICS

SINAMICS G120C SINAMICS G120C inverter

Compact Operating Instructions

<u>Fundamental safety instructions</u>	1
<u>Scope of delivery</u>	2
<u>Installing</u>	3
<u>Commissioning</u>	4
<u>Fault rectification</u>	5

Edition 07/2015, firmware 4.7 SP3

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

 DANGER
indicates that death or severe personal injury will result if proper precautions are not taken.
 WARNING
indicates that death or severe personal injury may result if proper precautions are not taken.
 CAUTION
indicates that minor personal injury can result if proper precautions are not taken.
NOTICE
indicates that property damage can result if proper precautions are not taken.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

 WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Fundamental safety instructions	6
1.1	General safety instructions	6
1.2	Industrial security	7
2	Scope of delivery	8
3	Installing	10
3.1	Mounting	10
3.2	Connecting	14
3.2.1	Optional components for the inverter	14
3.2.2	Connecting the line supply, motor, and other components	15
3.2.3	Installing the converter in compliance with EMC rules	18
3.2.4	Overview of the interfaces	19
3.2.5	Terminal strips	20
3.2.6	Default setting of the interfaces	24
3.2.7	Wiring the terminal strip	31
3.2.8	Fieldbus interface assignment	32
4	Commissioning	33
4.1	Overview of the commissioning tool	33
4.2	Commissioning with BOP-2 operator panel	34
4.2.1	Basic commissioning with BOP-2	35
4.2.2	Standard Drive Control	36
4.2.3	Dynamic Drive Control	38
4.2.4	Additional settings	42
4.2.4.1	Operating the inverter with the BOP-2	42
4.2.4.2	Changing the function of individual terminals	46
4.2.4.3	Releasing the failsafe function "Safe Torque Off" (STO)	48
4.2.4.4	Parameter list	49
5	Fault rectification	67
5.1	List of alarms and faults	67
5.2	Product support	73
5.3	Spare parts	73

This Getting Started Guide describes how you install and commission the SINAMICS G120C converter.

What is the meaning of the symbols in the manual?



1 An operating instruction starts here.



This concludes the operating instruction.

1

Fundamental safety instructions

1.1 General safety instructions

 **WARNING**

Risk of death if the safety instructions and remaining risks are not carefully observed

If the safety instructions and residual risks are not observed in the associated hardware documentation, accidents involving severe injuries or death can occur.

- Observe the safety instructions given in the hardware documentation.
- Consider the residual risks for the risk evaluation.

 **WARNING**

Danger to life or malfunctions of the machine as a result of incorrect or changed parameterization

As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death.

- Protect the parameterization (parameter assignments) against unauthorized access.
- Respond to possible malfunctions by applying suitable measures (e.g. EMERGENCY STOP or EMERGENCY OFF).

1.2 Industrial security

Note

Industrial security

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit this address (<http://www.siemens.com/industrialsecurity>).

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit this address (<http://support.automation.siemens.com>).

WARNING

Danger as a result of unsafe operating states resulting from software manipulation

Software manipulation (e.g. by viruses, Trojan horses, malware, worms) can cause unsafe operating states to develop in your installation which can result in death, severe injuries and/or material damage.

- Keep the software up to date.
You will find relevant information and newsletters at this address (<http://support.automation.siemens.com>).
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.
You will find further information at this address (<http://www.siemens.com/industrialsecurity>).
- Make sure that you include all installed products into the holistic industrial security concept.

2

Scope of delivery

The delivery comprises at least the following components:

- A ready to run inverter with loaded firmware. Options for upgrading and downgrading the firmware can be found on the Internet: Firmware (<http://support.automation.siemens.com/WW/news/en/67364620>)

The rated power and the fieldbus interface of the inverter are encrypted in the article number. You can find the Article number 6SL3210-1KE..., the hardware version (e.g. C02) and the firmware (e.g. V4.7) on the inverter rating plate.

- 1 set of connectors for connecting the inputs and outputs
- 1 set of connectors for connecting the line supply, motor, and braking resistor
- Only for inverters with fieldbus via USS or Modbus RTU: Connector for connecting the fieldbus
- 1 set of shield plates
- Compact Operating Instructions in German and English
- The inverter contains open-source software (OSS). The OSS license terms are saved in the inverter.

Reading the OSS license terms

The inverter contains open-source software (OSS). OSS comprises open source text and satisfies special license terms. If you wish to read the license terms, you must transfer them from the inverter to a PC.

Procedure





To transfer the OSS license terms from the inverter to a PC, proceed as follows:

1. Switch off the inverter power supply.
2. Insert an empty memory card into the card slot of the inverter. See also Section: Overview of the interfaces (Page 19)
3. Switch on the inverter power supply.
4. When you have switched on the power supply, wait 30 seconds.
During this time, the inverter writes the "Read_OSS.ZIP" file onto the memory card.
5. Switch off the inverter power supply.
6. Withdraw the memory card from the inverter.
7. Use a card reader and load the file to a PC.

- You have then transferred the OSS license terms from the inverter to a PC, and you can now read the license terms.

Rating plate and technical data

Frame size	Rated output power	Rated output current	Article No.	
	Based on a low overload		Without filter	With filter
 FSA	0.55 kW	1.7 A	6SL3210-1KE11-8U <input type="checkbox"/> 2	6SL3210-1KE11-8A <input type="checkbox"/> 2
	0.75 kW	2.2 A	6SL3210-1KE12-3U <input type="checkbox"/> 2	6SL3210-1KE12-3A <input type="checkbox"/> 2
	1.1 kW	3.1 A	6SL3210-1KE13-2U <input type="checkbox"/> 2	6SL3210-1KE13-2A <input type="checkbox"/> 2
	1.5 kW	4.1 A	6SL3210-1KE14-3U <input type="checkbox"/> 2	6SL3210-1KE14-3A <input type="checkbox"/> 2
SINAMICS G120C USS/MB (USS, Modbus RTU)			B	B
SINAMICS G120C DP (PROFIBUS)			P	P
SINAMICS G120C PN (PROFINET, EtherNet/IP)			F	F
 FSA	0.55 kW	1.7 A	6SL3210-1KE11-8U <input type="checkbox"/> 1	6SL3210-1KE11-8A <input type="checkbox"/> 1
	0.75 kW	2.2 A	6SL3210-1KE12-3U <input type="checkbox"/> 1	6SL3210-1KE12-3A <input type="checkbox"/> 1
	1.1 kW	3.1 A	6SL3210-1KE13-2U <input type="checkbox"/> 1	6SL3210-1KE13-2A <input type="checkbox"/> 1
	1.5 kW	4.1 A	6SL3210-1KE14-3U <input type="checkbox"/> 1	6SL3210-1KE14-3A <input type="checkbox"/> 1
	2.2 kW	5.6 A	6SL3210-1KE15-8U <input type="checkbox"/> 1	6SL3210-1KE15-8A <input type="checkbox"/> 1
	3.0 kW	7.3 A	6SL3210-1KE17-5U <input type="checkbox"/> 1	6SL3210-1KE17-5A <input type="checkbox"/> 1
	4.0 kW	8.8 A	6SL3210-1KE18-8U <input type="checkbox"/> 1	6SL3210-1KE18-8A <input type="checkbox"/> 1
 FSB	5.5 kW	12.5 A	6SL3210-1KE21-3U <input type="checkbox"/> 1	6SL3210-1KE21-3A <input type="checkbox"/> 1
	7.5 kW	16.5 A	6SL3210-1KE21-7U <input type="checkbox"/> 1	6SL3210-1KE21-7A <input type="checkbox"/> 1
 FSC	11.0 kW	25.0 A	6SL3210-1KE22-6U <input type="checkbox"/> 1	6SL3210-1KE22-6A <input type="checkbox"/> 1
	15.0 kW	31.0 A	6SL3210-1KE23-2U <input type="checkbox"/> 1	6SL3210-1KE23-2A <input type="checkbox"/> 1
	18.5 kW	37.0 A	6SL3210-1KE23-8U <input type="checkbox"/> 1	6SL3210-1KE23-8A <input type="checkbox"/> 1
SINAMICS G120C USS/MB (USS, Modbus RTU)			B	B
SINAMICS G120C DP (PROFIBUS)			P	P
SINAMICS G120C PN (PROFINET, EtherNet/IP)			F	F
SINAMICS G120C CANopen			C	C

① **SIEMENS**
Sinamics G120C ...

Input : 3AC ...
Output : 3AC ...
Motor : ...
Input : 3AC ...
Motor: IEC ...

6SL3210-1KE... Version : ... / V...

Serial No : ... www.siemens.com/sinamics

The inverter rating plate contains the most important technical data and the Article No. You will find a rating plate at the following locations on the inverter:

- At the front, after removing the blanking cover for the operator panel.
- At the side of the heat sink.

3

Installing

3.1 Mounting

Dimensions




Figure 3-1 Dimensions and minimum spacing to other devices

Table 3- 1 Dimensions

	Frame Size AA 0.55 kW ... 1.5 kW	Frame Size A 0.55 kW ... 4.0 kW	Frame size B 5.5 kW ... 7.5 kW	Frame size C 11 kW ... 18.5 kW
Height including connectors	181 mm	196 mm	196 mm	295 mm
Height including shield plate	268 mm	276 mm	276 mm	375 mm
Width	73 mm	73 mm	100 mm	140 mm
Depth of the inverter with PROFINET interface	178 mm	226 mm	226 mm	226 mm
Depth of the inverter with USS/MB, CANopen, or PROFIBUS interface	155 mm	203 mm	203 mm	203 mm
Additional depth when the Operator Panel is attached	+ 21 mm with IOP (Intelligent Operator Panel) plugged in			
	+ 11 mm with BOP-2 (Basic Operator Panel) plugged in			

Mounting shield plates

We recommend that you mount the shield plates provided. The shield plates make it simpler to install the inverter in compliance with EMC regulations and to provide strength relief for the connected cables.





Figure 3-2 Mounting a shield plate using as example a frame size A inverter

Mounting on a control cabinet panel

Table 3-2 Drilling patterns and mounting equipment

	Frame Size AA 0.55 kW ... 1.5 kW	Frame Size A 0.55 kW ... 4.0 kW	Frame size B 5.5 kW ... 7.5 kW	Frame size C 11 kW ... 18.5 kW
Drilling pattern	<p>Drilling pattern without shield plate When the shield plate is mounted, the drilling pattern is compatible to frame size A</p>			
Mounting parts	2 x M4 bolts 2 x M4 nuts 2 x M4 washers	3 x M4 studs, 3 x M4 nuts, 3 x M4 washers	4 x M4 studs, 4 x M4 nuts, 4 x M4 washers	4 x M5 studs, 4 x M5 nuts, 4 x M5 washers
Locked-rotor (starting) torque	2.5 Nm	2.5 Nm	2.5 Nm	2.5 Nm

Mounting on a mounting rail (TS 35)



You can mount inverters, frame size FSA on a TS 35 mounting rail.

Procedure



Proceed as follows to mount the inverter on a mounting rail:

1. Mount the inverter on the top edge of the mounting rail.
2. Using a screwdriver, actuate the release button on the upper side of the inverter.
3. Continue to actuate the release button until the inverter audibly snaps onto the mounting rail.




Figure 3-3 Mounting on a standard mounting rail

You have mounted the inverter on a mounting rail.



To remove, actuate the release button and at the same time withdraw the inverter from the mounting rail.

Mounting on a base component (only frame size FSAA)

Reactors, filters and braking resistors are available as base components for inverters, frame size FSAA.

Mount the inverter using two M4 screws on the base component.




Figure 3-4 Available base components

You can combine up to two base components.




Figure 3-5 Permissible combination of two base components

3.2 Connecting

3.2.1 Optional components for the inverter

Braking resistor

The braking resistor allows the inverter to actively brake loads with high moments of inertia

Line reactor

The line reactor increases the level of protection for the inverter against overvoltages, harmonics and commutation dips.

Note

In order that the inverter service life is not reduced, a line reactor is required for a relative short-circuit voltage u_k of the line transformer $< 1\%$.

Output choke

The output reactor increases the maximum permissible length of the motor cables.

Assignment of the inverter to braking resistor, line reactor and output reactor

6SL3210-... inverter			Braking resistor	Line reactor	Output choke
Frame size AA, A	0.55 kW ... 1.1 kW	...1KE11-8□□□, ...1KE12-3□□□, ...1KE13-2□□□	6SL3201-0BE14-3AA0	6SL3203-0CE13-2AA0	6SL3202-0AE16-1CA0
	1.5 kW	...1KE14-3□□□		6SL3203-0CE21-0AA0	
Frame size A	2.2 kW	...1KE15-8□□1	6SL3201-0BE21-0AA0		6SL3202-0AE18-8CA0
	3.0 kW ... 4.0 kW	...1KE17-5□□1, ...1KE18-8□□1			6SL3202-0AE21-8CA0
Frame size B	5.5 kW ... 7.5 kW	...1KE21-3□□1, ...1KE21-7□□1	6SL3201-0BE21-8AA0	6SL3203-0CE21-8AA0	6SL3202-0AE21-8CA0
Frame size C	11.0 kW ... 18.5 kW	...1KE22-6□□1, ...1KE23-2□□1, ...1KE23-8□□1	6SL3201-0BE23-8AA0	6SL3203-0CE23-8AA0	6SL3202-0AE23-8CA0

3.2.2 Connecting the line supply, motor, and other components




! WARNING

Danger to life caused by high leakage currents when the external PE conductor is interrupted

Drive components conduct high leakage currents through the PE conductor. When the PE conductor is interrupted, touching live components can result in electric shock, which can lead to death or serious injuries.


- Ensure that the external PE conductor complies with at least one of the following conditions:
 - It is laid protected against mechanical damage.¹⁾
 - As a core of a multi-core cable, it has a cross section of at least 2.5 mm² Cu.
 - It has a parallel, second PE conductor with the same cross section.
 - It complies with the local regulations for equipment with increased leakage current.


¹⁾ Cables routed in control cabinets or enclosed machine enclosures are considered to be adequately protected against mechanical damage.



Frame size, rated power	Converter			
	Connection cross-section (tightening torque)			
FSAA, FSA 0.55 kW ... 4.0 kW	1.0 ... 2.5 mm ²	(0.5 Nm)	18 ... 14 AWG	(4.5 lbf in)
FSB 5.5 kW ... 7.5 kW	4.0 ... 6.0 mm ²	(0.6 Nm)	12 ... 10 AWG	(5.5 lbf in)
FSC 11 kW 15 kW ... 18.5 kW	6.0 ... 16 mm ²	(1.5 Nm)	10 ... 5 AWG	(13.5 lbf in)
	10 ... 16 mm ²	(1.5 Nm)	7 ... 5 AWG	(13.5 lbf in)

Rated power of the inverter	Line reactor				
	Connection cross-section (tightening torque)				
0.55 kW ... 4.0 kW	2.5 mm ²	(0.8 Nm)	14 AWG	(7 lbf in)	PE M4 (3 Nm / 27 lbf in) PE M5 (5 Nm / 44 lbf in)
5.5 kW ... 7.5 kW	6 mm ²	(1.8 Nm)	10 AWG	(16 lbf in)	
11 kW ... 18.5 kW	16 mm ²	(4 Nm)	5 AWG	(35 lbf in)	

Rated power of the inverter		Output choke Connection cross-section (tightening torque)		
		0.55 kW ... 4.0 kW	2.5 mm ² (0.8 Nm)	14 AWG (7 lbf in)
5.5 kW ... 7.5 kW		10 mm ² (1.8 Nm)	8 AWG (16 lbf in)	PE M5 (5 Nm / 44 lbf in)
11 kW ... 18.5 kW		16 mm ² (4 Nm)	5 AWG (35 lbf in)	

Rated power of the inverter		Braking resistor Connection cross-section (tightening torque)			
		R1, R2, PE		Temperature contact	
0.55 kW ... 7.5 kW		2.5 mm ² (0.5 Nm)	14 AWG (4.5 lbf in)	2.5 mm ² (0.5 Nm)	14 AWG (4.5 lbf in)
11 kW ... 18.5 kW		6 mm ² (0.6 Nm)	10 AWG (5.5 lbf in)		

Converter Frame size, rated power			Reactor, filter or braking resistor as base components Connection cross-section (tightening torque)	
FSA	0.55 kW ... 1.5 kW		1.0 ... 2.5 mm ² (1.1 Nm)	17 ... 14 AWG (10 lbf in)

Procedure




To connect the inverter and its components, proceed as follows:

1. Install the appropriate fuses:

Converter		Fuse according to IEC	Fuse according to UL/cUL
FSA, FSA	0.55 kW ... 1.1 kW	3NA3801 (6 A)	10 A, 600 V _{AC} , Class J
	1.5 kW ... 2.2 kW	3NA3803 (10 A)	
	3.0 kW ... 4.0 kW	3NA3805 (16 A)	
FSB	5.5 kW	3NA3807 (20 A)	20 A, 600 V _{AC} , Class J
	7.5 kW	3NA3810 (25 A)	
FSC	11 kW	3NA3817 (40 A)	40 A, 600 V _{AC} , Class J
	15 kW	3NA3820 (50 A)	
	18.5 kW	3NA3822 (63 A)	

2. Connect the inverter and its components.
The plugs for connecting the line supply, motor, and braking resistor can be found on the lower side of the inverter.
3. If an EMC-compliant installation is required, you must use shielded cables. See also Section: Installing the converter in compliance with EMC rules (Page 18).



- You have now connected the inverter and its components.

Installation in the United States and Canada (UL or CSA)

To install the inverter in compliance with UL/cUL, perform the following steps:

- Use UL/CSA Class J fuses.
- A multi-motor drive is not permissible, i.e. simultaneously operating several motors connected to one inverter.
- The integrated semiconductor short-circuit protection in the inverter does not provide branch protection. Install branch protection in compliance with the National Electric Code and possibly relevant local regulations.
- The following restrictions apply to the minimum size of the electrical cabinet:
 - Inverters, frame size FSAA: $\geq 30000 \text{ cm}^3$ ($\geq 1830 \text{ in}^3$)
 - Inverters, frame sizes FSA ... FSC No restrictions regarding UL regulations
- Install the inverters in line supplies $\leq 40000 \text{ A}$ (symmetrical, $\leq 480 \text{ V}$).
- Use copper cables, Class 1, $\geq 60^\circ \text{ C}$ for frame size FSAA.
- Use copper cables, Class 1, 75° C for frame sizes FSA ... FSC.
- Leave parameter p0610 in its factory setting.


The factory setting p0610 = 12 means: The inverter responds to motor overtemperature immediately with an alarm and after a certain time with a fault.

Additional requirements for CSA compliance:

- Use a surge protection device with Article No. 5SD7424-1.
- Alternative: Install the inverter with an external surge protection device with the following attributes:
 - Surge protection device with 'listed' test symbol: category checking numbers VZCA and VZCA7
 - Rated voltage 3-phase 480/277 V AC, 50/60 Hz
 - Terminal voltage $V_{PR} = 2000 \text{ V}$, $I_N = 3 \text{ kA min}$, $MCOV = 508 \text{ VAC}$, $SCCR = 40 \text{ kA}$
 - Suitable for SPD applications, type 1 or type 2
- When commissioning the drive system, set the motor overload protection to 115 %, 230 % or 400 % of the rated motor current using parameter p0640. This means that motor overload protection according to CSA C22.2 No. 274 is complied with.

3.2.3 Installing the converter in compliance with EMC rules

Overview



Rules for cable installation to ensure EMC

- Install the inverter on a metal mounting plate. The mounting plate must be unpainted and highly electrically conductive.
- Use shielded cables for the following connections:
 - Motor and motor temperature sensor
 - Braking resistor (not available for all inverters)
 - Fieldbus
 - Inputs and outputs of the terminal strip
- Connect the cable shields to ensure EMC:





Figure 3-6 Examples of correct EMC-compliant shield connection

3.2.4 Overview of the interfaces


Interfaces at the front of the Control Unit

To access the interfaces at the front of the Control Unit, you must unplug the Operator Panel (if one is being used) and open the front doors.



3.2.5 Terminal strips

Wiring variations of the terminal strips



GND All terminals with the reference potential "GND" are connected to each other inside the inverter.

DI COM1 The reference potentials "DI COM1" and "DI COM2" are galvanically isolated from "GND."

DI COM2 → If you use the 24-V power supply at terminal 9 to power the digital inputs, you must interconnect "GND," "DI COM1," and "DI COM2."

Terminals 31, 32: When an optional 24-V power supply is connected to terminals 31, 32, the Control Unit remains in operation even after the Power Module has been disconnected from the line supply. The Control Unit thus maintains fieldbus communication, for example.

GND IN → Connect only power supplies that are SELV (Safety Extra Low Voltage) or PELV (Protective Extra Low Voltage) to terminals 31, 32 .


→ If you also wish to use the power supply at terminals 31, 32 for the digital inputs, then you must connect "DI COM1/2" and "GND IN" with one another.

Terminals 3, 4: For the analog input, you can use the internal 10-V power supply or an external voltage source. Typical current consumption: 10 mA ... 20 mA.

→ If you use the internal 10-V supply, you must connect AI 0- to GND.


Figure 3-7 Example of wiring digital inputs with the inverter's internal 24-V power supply

Further wiring options for digital inputs



If you want to connect the potential of the external power source to the potential of the inverter's internal power supply, you must connect "GND" to terminals 34 and 69.

Connection of contacts switching to P potential with an external power source



Connect terminals 69 and 34 to each other.

Connection of contacts switching to N potential with an external power source

Factory settings of the terminal strip

The factory setting of the terminals depends on whether the inverter has a PROFIBUS / PROFINET interface.

31	+24V IN	
32	GND IN	
1	+10V out	
2	GND	
3	AI 0+	Speed setpoint (-10 V ... 10 V)
4	AI 0-	
⊗	12 AO 0+	Actual speed value (0 mA ... 20 mA)
	13 GND	
	21 DO 1 POS	Alarm
⊗	22 DO 1 NEG	
	14 T1 MOTOR	---
	15 T2 MOTOR	---
	28 GND	
	69 DI COM1	
	34 DI COM2	
/	5 DI 0	ON/OFF1
/	6 DI 1	Reversing direction of rotation
/	7 DI 2	Acknowledge fault
	8 DI 3	---
	16 DI 4	---
	17 DI 5	---

	18 DO 0 NC	Fault
	19 DO 0 NO	
⊗	20 DO 0 COM	
9	+24V out	

Figure 3-8 Factory setting of the terminals for G120C USS and G120C CAN




Figure 3-9 Factory setting of the terminals for G120C DP and G120C PN

Changing the function of the terminals

The function of the terminals marked in color in the two diagrams above, can be set.

In order not to have to successively change terminal for terminal, several terminals can be jointly set using default settings ("p0015 Macro drive unit").

The terminal settings made in the factory described above correspond to the following default settings:

- Default setting 12 (p0015 = 12): "Standard I/O with analog setpoint"
- Default setting 7 (p0015 = 7): "Fieldbus with data set switchover"

3.2.6 Default setting of the interfaces

Default setting 1: "Conveyor technology with 2 fixed frequencies"

—	5	DI 0	ON/OFF1 clockwise
—	6	DI 1	ON/OFF1 counterclockwise
—	7	DI 2	Acknowledge fault
—	16	DI 4	Fixed speed setpoint 3
—	17	DI 5	Fixed speed setpoint 4
⊗	18	DO 0	Fault
	19		
	20		
⊗	21	DO 1	Alarm
	22		
⊖	12	AO 0	Speed actual value


DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5
 Fixed speed setpoint 3: p1003, fixed speed setpoint 4: p1004, fixed speed setpoint active: r1024
 Speed setpoint (main setpoint): p1070[0] = 1024
 DI 4 and DI 5 = high: the inverter adds the two fixed speed setpoints
 Designation in the BOP-2: coN 2 SP

Default setting 2: "Conveyor system with Basic Safety"

—	5	DI 0	ON/OFF1 with fixed speed setpoint 1
—	6	DI 1	Fixed speed setpoint 2
—	7	DI 2	Acknowledge fault
—	16	DI 4	} Reserved for a safety function
—	17	DI 5	
⊗	18	DO 0	Fault
	19		
	20		
⊗	21	DO 1	Alarm
	22		
⊖	12	AO 0	Speed actual value


DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5
 Fixed speed setpoint 1: p1001, fixed speed setpoint 2: p1002, fixed speed setpoint active: r1024
 Speed setpoint (main setpoint): p1070[0] = 1024
 DI 0 and DI 1 = high: the inverter adds the two fixed speed setpoints.
 Designation in the BOP-2: coN SAFE

Default setting 3: "Conveyor system with 4 fixed frequencies"




DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5
 Fixed speed setpoint 1: p1001, ... fixed speed setpoint 4: p1004, fixed speed setpoint active: r1024
 Speed setpoint (main setpoint): p1070[0] = 1024
 Several of the DI 0, DI 1, DI 4, and DI 5 = high: the inverter adds the corresponding fixed speed setpoints.
 Designation in the BOP-2: coN 4 SP

Default setting 4: "Conveyor system with fieldbus"



DO 0: p0730, DO 1: p0731 AO 0: p0771[0]
 Speed setpoint (main setpoint): p1070[0] = 2050[1]
 Designation in the BOP-2: coN Fb


Default setting 5: "Conveyor system with fieldbus and Basic Safety"



DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 4: r0722.4, DI 5: r0722.5
 Speed setpoint (main setpoint): p1070[0] = 2050[1]
 Designation in the BOP-2: coN Fb S


Default setting 7: "Fieldbus with data set switchover"

Factory setting for inverters with PROFIBUS or PROFINET interface




DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 3: r0722.3
 Speed setpoint (main setpoint): p1070[0] = 2050[1]
 Jog 1 speed setpoint: p1058, factory setting: 150 rpm
 Jog 2 speed setpoint: p1059, factory setting: -150 rpm
 Designation in the BOP-2: FB cdS

Default setting 8: "MOP with Basic Safety"



DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5
 Motorized potentiometer, setpoint after the ramp-function generator: r1050
 Speed setpoint (main setpoint): p1070[0] = 1050
 Designation in the BOP-2: MoP SAFE


Default setting 9: "Standard I/O with MOP"



DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 3: r0722.3
 Motorized potentiometer, setpoint after the ramp-function generator: r1050
 Speed setpoint (main setpoint): p1070[0] = 1050
 Designation in the BOP-2: Std MoP


Default setting 12: "Standard I/O with analog setpoint"

Factory setting for inverters with USS interface




DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 2: r0722.2 AI 0: r0755[0]
 Speed setpoint (main setpoint): p1070[0] = 755[0]
 Designation in the BOP-2: Std ASP

Default setting 13: "Standard I/O with analog setpoint and safety"



DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5 AI 0: r0755[0]
 Speed setpoint (main setpoint): p1070[0] = 755[0]
 Designation in the BOP-2: ASPS

Default setting 14: "Process industry with fieldbus"




DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5

Motorized potentiometer, setpoint after the ramp-function generator: r1050

Speed setpoint (main setpoint): p1070[0] = 2050[1], p1070[1] = 1050


Designation in the BOP-2: Proc Fb

Default setting 15: "Process industry"



DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 5: r0722.5 AI 0: r0755[0]
 Motorized potentiometer, setpoint after the ramp-function generator: r1050
 Speed setpoint (main setpoint): p1070[0] = 755[0], p1070[1] = 1050
 Designation in the BOP-2: Proc

Default setting 17: "2-wire (forw/backw1)"



DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 2: r0722.2 AI 0: r0755[0]
 Speed setpoint (main setpoint): p1070[0] = 755[0]
 Designation in the BOP-2: 2-wlrE 1

Default setting 18: "2-wire (forw/backw2)"

—	5	DI 0	ON/OFF1 clockwise
—	6	DI 1	ON/OFF counterclockwise
—	7	DI 2	Acknowledge fault
↕	3	AI 0+	Speed setpoint
⊗	18	DO 0	Fault
	19		
	20		
⊗	21	DO 1	Alarm
	22		
⊖	12	AO 0	Speed actual value

DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 2: r0722.2 AI 0: r0755[0]
 Speed setpoint (main setpoint): p1070[0] = 755[0]
 Designation in the BOP-2: 2-wlrE 2

Default setting 19: "3-wire (enable/forw/backw)"

—	5	DI 0	Enable/OFF1
—	6	DI 1	ON clockwise
—	7	DI 2	ON counterclockwise
—	16	DI 4	Acknowledge fault
↕	3	AI 0+	Speed setpoint
⊗	18	DO 0	Fault
	19		
	20		
⊗	21	DO 1	Alarm
	22		
⊖	12	AO 0	Speed actual value


DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 4: r0722.4 AI 0: r0755[0]
 Speed setpoint (main setpoint): p1070[0] = 755[0]
 Designation in the BOP-2: 3-wlrE 1

Default setting 20: "3-wire (enable/on/reverse)"


—	5	DI 0	Enable/OFF1
—	6	DI 1	ON
—	7	DI 2	Reversing
—	16	DI 4	Acknowledge fault
↕	3	AI 0+	Speed setpoint
⊗	18	DO 0	Fault
	19		
	20		
⊗	21	DO 1	Alarm
	22		
⊖	12	AO 0	Speed actual value

DO 0: p0730, DO 1: p0731 AO 0: p0771[0] DI 0: r0722.0, ..., DI 4: r0722.4 AI 0: r0755[0]
 Speed setpoint (main setpoint): p1070[0] = 755[0]
 Designation in the BOP-2: 3-wlrE 2

Default setting 21: "USS fieldbus"







Default setting 22: "CAN fieldbus"



3.2.7 Wiring the terminal strip

Table 3- 3 Permissible cables and wiring options


Solid or finely stranded cable	Flexible conductor with non-insulated end sleeve	Flexible conductor with non-insulated end sleeve	Two finely stranded cables with the same cross-section with partially insulated twin end sleeves
 0.5 ... 1.5 mm ²	 0.5 ... 1.0 mm ²	 0.5 mm ²	 2 * 0.5 mm ²

Wiring the terminal strip to ensure EMC

- If you use shielded cables, you must connect the shield to the mounting plate of the control cabinet or to the shield contact of the inverter over a large surface area and highly conductively.
See also: EMC installation guideline
(<http://support.automation.siemens.com/WW/view/en/60612658>)
- Use the shield connection plate of the inverter as strain relief.

3.2.8 Fieldbus interface assignment

The fieldbus interface is on the underside of the converter.



Description files for fieldbuses


The description files are electronic device data sheets which contain all the required information of a higher-level controller. You can configure and operate the inverter on a fieldbus with the appropriate description file.

Description file	Download	Alternative to download
Generic Station Description (GSD) for PROFIBUS	Internet: (http://support.automation.siemens.com/WW/view/en/23450835)	GSD and GSDML are saved in the inverter. The inverter writes its GSD or GSDML to the memory card once you insert this card in the inverter and set p0804 = 12. You can then transfer the file to your programming device or PC using the memory card.
GSD Markup Language (GSDML) for PROFINET	Internet: (http://support.automation.siemens.com/WW/view/en/26641490)	
Electronic Data Sheet (EDS) for CANopen	Internet: (http://support.automation.siemens.com/WW/view/en/48351511)	---
EDS for Ethernet/IP	Internet: (http://support.automation.siemens.com/WW/view/en/78026217)	---

Commissioning

4.1 Overview of the commissioning tool

The following tools are used to commission, troubleshoot and control the inverter, as well as to back up and transfer the inverter settings.

Operator panels		Article number
 <p>BOP-2 (Basic Operator Panel) - for snapping onto the inverter</p> <ul style="list-style-type: none"> Two-line display Guided basic commissioning 		<p>Door mounting kit for IOP/BOP-2</p> <ul style="list-style-type: none"> For installation of the BOP-2 or IOP in a control cabinet door. Degree of protection with IOP: IP54 or UL Type 12 Degree of protection with BOP-2: IP55
 <p>IOP (Intelligent Operator Panel) - for snapping onto the inverter</p> <ul style="list-style-type: none"> Plain text display Menu-based operation and application wizards 		<p>BOP-2: 6SL3255-0AA00-4CA1</p> <p>IOP with European languages: 6SL3255-0AA00-4JA1</p> <p>IOP with Chinese: 6SL3255-0AA00-4JC1</p> <p>Door mounting kit: 6SL3256-0AP00-0JA0</p>
	<p>For mobile use of the IOP: IOP handheld with power supply unit and rechargeable batteries as well as RS232 connection cable</p> <p>If you are using your own connection cable, carefully note the maximum permissible length of 5 m.</p>	6SL3255-0AA00-4HA0
PC tools		
 	<p>STARTER Connected to the inverter via USB port, PROFIBUS or PROFINET</p> <p>Download: STARTER (http://support.automation.siemens.com/WW/view/en/26233208)</p>	STARTER on DVD: 6SL3072-0AA00-0AG0
	<p>Startdrive Connected to the inverter via USB port, PROFIBUS or PROFINET</p> <p>Download: Startdrive (http://support.automation.siemens.com/WW/view/en/68034568)</p>	Startdrive on DVD: 6SL3072-4CA02-1XG0
	<p>SINAMICS PC Inverter Connection Kit 2 Contains the correct USB cable (3 m) to connect a PC to the inverter.</p>	6SL3255-0AA00-2CA0

If you intend to commission the converter with IOP operator panel

The IOP offers commissioning wizards and help texts for an intuitive commissioning. For further information refer to the IOP operating instructions.

If you intend to commission the converter with PC tool STARTER

Overview of the most important steps:

1. Connect the PC to the converter via USB and start the STARTER tool.
2. Choose the project wizard (menu "Project / New with assistant").
 - In the project wizard choose "Find drive units online".
 - Select USB as interface (Access point of the application: "DEVICE ...", interface parameter assignment used: "S7USB").
 - Finish the project wizard.
3. STARTER has now created your project and inserted a new drive.
 - Select the drive in your project and go online .
 - In your drive open the "Configuration" mask (double click).
 - Start commissioning with the "Assistent" button.

For further information refer to converter operating instructions.

4.2 Commissioning with BOP-2 operator panel

Plug Basic Operator Panel BOP-2 into the inverter

Procedure

-  1 To plug Basic Operator Panel BOP-2 onto the inverter, proceed as follows:
1. Remove the blanking cover of the inverter.
 2. Locate the lower edge of the BOP-2 housing in the matching recess of the inverter housing.
 3. Press the BOP-2 onto the inverter until you hear the latching mechanism on the inverter housing engage.

-  You have plugged the BOP-2 onto the inverter
- When you power up the inverter, the BOP-2 will be ready for operation.



4.2.1 Basic commissioning with BOP-2

Carry out basic commissioning

Preconditions




- The power supply is switched on.
- The operator panel displays setpoints and actual values.

Procedure




Proceed as follows to carry out basic commissioning:

1.  Press the ESC key.
2.  Press one of the arrow keys until the BOP-2 displays the "SETUP" menu.
3.  In the "SETUP" menu, press the OK key to start basic commissioning.
4.  If you wish to restore all of the parameters to the factory setting before the basic commissioning:
 - 4.1. Switch over the display using an arrow key: nO → YES
 - 4.2. Press the OK key.
5.  When you select an application class, the inverter assigns suitable default settings to the motor control:
 - STANDARD Standard Drive Control (Page 36)
 - DYNAMIC Dynamic Drive Control (Page 38)
 - EXPERT This procedure is described in the operating instructions → Product support (Page 73)

Select the suitable application class

When you select an application class, the inverter assigns suitable settings to the motor control:

Application class	Standard Drive Control	Dynamic Drive Control
Motors that can be operated	Induction motors	Induction and synchronous motors
Application examples	<ul style="list-style-type: none"> • Pumps, fans, and compressors with flow characteristic • Wet or dry blasting technology • Mills, mixers, kneaders, crushers, agitators • Horizontal conveyor technology (conveyor belts, roller conveyors, chain conveyors) • Basic spindles 	<ul style="list-style-type: none"> • Pumps and compressors with displacement machines • Rotary furnaces • Extruder • Centrifuge

Application class	Standard Drive Control	Dynamic Drive Control
<p>Characteristics</p> <ul style="list-style-type: none"> • Typical settling time after a speed change: 100 ms ... 200 ms • Typical settling time after a sudden load change: 500 ms • Standard Drive Control is suitable for the following requirements: <ul style="list-style-type: none"> – All motor power ratings – Ramp-up time 0 → rated speed (depending on the motor power rating): 1 s (0.1 kW) ... 10 s (18.5 kW) – Applications with continuous load torque without sudden load changes • Standard Drive Control is insensitive to inaccurate motor data settings 		<ul style="list-style-type: none"> • Typical settling time after a speed change: < 100 ms • Typical settling time after a sudden load change: 200ms • Dynamic Drive Control controls and limits the motor torque • Typically achieves a torque accuracy: ± 5 % for 15 % ... 100 % of the rated speed • We recommend Dynamic Drive Control for the following applications: <ul style="list-style-type: none"> – Motor power ratings > 11 kW – On sudden load changes 10% ... >100% of the motor rated torque • Dynamic Drive Control is necessary for a ramp-up time 0 → rated speed (depending on the motor power rating): < 1 s (0.1 kW) ... < 10 s (18.5 kW).
<p>Max. output frequency</p>	<p>550 Hz</p>	<p>240 Hz</p>
<p>Commissioning</p>	<ul style="list-style-type: none"> • Unlike "Dynamic Drive Control," no speed controller needs to be set • As compared with "configuration for experts": <ul style="list-style-type: none"> – Simplified commissioning using predefined motor data – Reduced number of parameters 	<ul style="list-style-type: none"> • Reduced number of parameters as compared with "configuration for experts"

4.2.2 Standard Drive Control

- 6. Motor standard
KW 50HZ IEC
HP 60HZ NEMA
KW 60HZ IEC 60 Hz
- 7. Supply voltage for the inverter

8. Enter the motor data:

8.1.  MOT TYPE
P300 

Motor type

Depending on the particular inverter, it is possible that the BOP-2 does not list all of the following motor types.


INDUCT	Third-party induction motor
SYNC	Third-party synchronous motor
RELUCT	Third-party reluctance motor
1L... IND	1LE1, 1LG6, 1LA7, 1LA9 induction motors
1LE1 IND 100	1LE1□9 with motor code on the rating plate
1PH8 IND	Induction motor
1FP1	Reluctance motor
1F... SYN	1FG1, 1FK7 synchronous motor, without encoder

8.2.  MOT CODE
P301 

If you have selected a motor type > 100, then you must enter the motor code:


With the correct motor code, the inverter assigns the motor data the following values.

If you do not know the motor code, then you must set the motor code = 0, and enter the motor data from p0304 and onwards from the rating plate.

8.3.  87 HZ 

87 Hz motor operation

The BOP-2 only displays this step if you previously selected IEC as the motor standard (EUR/USA, P100 = KW 50HZ).

8.4.  MOT VOLT
P304 


Rated voltage

8.5.  MOT CURR
P305 

Rated current

8.6.  MOT POW
P307 

Rated power

8.7.  MOT FREQ
P310 

Rated frequency

8.8.  MOT RPM
P311 

Rated speed



8.9.  MOT COOL
P335 

Motor cooling

SELF	Natural cooling
FORCED	Forced-air cooling
LIQUID	Liquid cooling
NO FAN	Without fan

9. TEC APPL
P501 OK Select the application:
 VEC STD Constant load: Typical applications include belt conveyor drives.
 PUMP FAN Speed-dependent load: Typical applications include pumps and fans.

 10. MAc PAR
P15 OK Select the default setting for the interfaces of the inverter that is suitable for your application. You will find the available default settings in Section: Default setting of the interfaces (Page 24)

 11. MIN RPM
P1080 OK Minimum and maximum motor speed
 12. MAX RPM
P1082 OK
- 
-
13. RAMP UP
P1120 OK Motor ramp-up time
 14. RAMP DWN
P1121 OK Motor ramp-down time
- 
-
15. OFF3 RP
P1135 OK Ramp-down time for the OFF3 command
 16. FINISH OK Complete the basic commissioning:
 - 16.1. Switch over the display using an arrow key: nO → YES
 - 16.2. Press the OK key.
- You have entered all of the data that is necessary for the basic commissioning of your inverter.

4.2.3 Dynamic Drive Control

6. EUR/USA
P100 OK Motor standard
 KW 50HZ IEC
 HP 60HZ NEMA
 KW 60HZ IEC 60 Hz
7. INV VOLT
P210 OK Supply voltage for the inverter

8. Enter the motor data:

8.1.  MOT TYPE
P300 

Motor type

Depending on the particular inverter, it is possible that the BOP-2 does not list all of the following motor types.


INDUCT	Third-party induction motor
SYNC	Third-party synchronous motor
RELUCT	Third-party reluctance motor
1L... IND	1LE1, 1LG6, 1LA7, 1LA9 induction motors
1LE1 IND 100	1LE1□9 with motor code on the rating plate
1PH8 IND	Induction motor
1FP1	Reluctance motor
1F... SYN	1FG1, 1FK7 synchronous motor, without encoder

8.2.  MOT CODE
P301 

If you have selected a motor type > 100, then you must enter the motor code:


With the correct motor code, the inverter assigns the motor data the following values.

If you do not know the motor code, then you must set the motor code = 0, and enter the motor data from p0304 and onwards from the rating plate.

8.3.  87 HZ 

87 Hz motor operation


The BOP-2 only displays this step if you previously selected IEC as the motor standard (EUR/USA, P100 = KW 50HZ).

8.4.  MOT VOLT
P304 

Rated voltage

8.5.  MOT CURR
P305 

Rated current

8.6.  MOT POW
P307 

Rated power

8.7.  MOT FREQ
P310 

Rated frequency

8.8.  MOT RPM
P311 

Rated speed

8.9.  MOT COOL
P335 

Motor cooling

SELF	Natural cooling
FORCED	Forced-air cooling
LIQUID	Liquid cooling
NO FAN	Without fan

9.

Select the application:

OP LOOP Recommended setting for standard applications.

CL LOOP Recommended setting for applications with short ramp-up and ramp-down times. This setting is not suitable for hoisting gear and cranes/lifting gear.

HVY LOAD Recommended setting for applications with a high break loose torque.


10.

Select the default setting for the interfaces of the inverter that is suitable for your application. You will find the available default settings in Section: Default setting of the interfaces (Page 24)

11.

Minimum and maximum motor speed

12.




13.

Motor ramp-up time

14.

Motor ramp-down time



15.

Ramp-down time for the OFF3 command

16.

Motor data identification

Select the method which the inverter uses to measure the data of the connected motor:

OFF Motor data is not measured.

ST RT OP Recommended setting: Measure the motor data at standstill and with the motor rotating.

STILL OP Measure the motor data at standstill.

Select this setting if the motor cannot rotate freely – for example, if the traversing range is mechanically limited.

17.

Complete the basic commissioning:

17.1. Switch over the display using an arrow key: nO → YES

17.2. Press the OK key.



You have entered all of the data that is necessary for the basic commissioning of your inverter.

Identifying the motor data and optimizing the closed-loop control

The inverter has several techniques to automatically identify the motor data and optimize the speed control.

To start the motor data identification routine, you must switch-on the motor via the terminal strip, fieldbus or from the operator panel.

 WARNING
<p>Risk of death due to machine motion while motor data identification is active</p> <p>For the stationary measurement, the motor can make several rotations. The rotating measurement accelerates the motor up to its rated speed. Secure dangerous machine parts before starting motor data identification:</p> <ul style="list-style-type: none"> • Before switching on, ensure that nobody is working on the machine or located within its working area. • Secure the machine's work area against unintended access. • Lower hanging/suspended loads to the floor.

Preconditions

- In the basic commissioning, you have selected a motor data identification method, e.g. measuring the motor data at standstill

After basic commissioning has been completed, the inverter outputs alarm A07991.

	This is symbol in the BOP-2 indicates an active alarm.
---	--

- The motor has cooled down to the ambient temperature.

An excessively high motor temperature falsifies the motor data identification results.

Procedure when using the BOP-2 operator panel



To start the motor data identification, proceed as follows:


1.  ⇒  Press the HAND/AUTO key. The BOP-2 displays the symbol for manual operation.
 2.  Switch on the motor.
 3.  The motor data identification takes several seconds.
Wait until the inverter switches off the motor after motor data identification has been completed.
-  If you have also selected a rotating measurement in addition to the motor data identification, then the inverter again issues the alarm A07991.

4.  Switch the motor on again in order to optimize the rotating measurement.
5.  Wait until the inverter switches off the motor after completion of the optimization. The optimization time depends on the rated motor power: 20 s ... 2 min.
6.  Switch the inverter control from HAND to AUTO.

 You have now completed motor data identification.

4.2.4 Additional settings

4.2.4.1 Operating the inverter with the BOP-2



1) Status display once the power supply for the inverter has been switched on.

Figure 4-1 Menu of the BOP-2




Figure 4-2 Other keys and symbols of the BOP-2

Procedure for switching the motor on and off via the operator panel:

1. Press MANUAL AUTO 
2. Master control of the inverter is released via the BOP-2 
3. Switch on motor 
4. Switch off the motor 

Changing settings using BOP-2

You can modify the settings of your inverter by changing the values of its parameters. The inverter only permits changes to "write" parameters. Write parameters begin with a "P", e.g. P45.


The value of a read-only parameter cannot be changed. Read-only parameters begin with an "r", for example: r2.

Procedure



To change write parameters using the BOP-2, proceed as follows:

1. Select the menu to display and change parameters. Press the OK key.
2. Select the parameter filter using the arrow keys. Press the OK key.
 - STANDARD: The inverter only displays the most important parameters.
 - EXPERT: The inverter displays all of the parameters.



3. Select the required number of a write parameter using the arrow keys. Press the OK key.
4. Select the value of the write parameter using the arrow keys. Accept the value with the OK key.

 You have now changed a write parameter using the BOP-2.

The inverter saves all the changes made using the BOP-2 so that they are protected against power failure.

Changing indexed parameters

For indexed parameters, several parameter values are assigned to a parameter number. Each of the parameter values has its own index.


Procedure



To change an indexed parameter, proceed as follows:

1. Select the parameter number.
2. Press the OK key.
3. Set the parameter index.
4. Press the OK key.
5. Set the parameter value for the selected index.

■ You have now changed an indexed parameter.



Directly select the parameter number

The BOP-2 offers the possibility of setting the parameter number digit by digit.

Precondition

The parameter number is flashing in the BOP-2 display.


Procedure



To select the parameter number directly, proceed as follows:

1. Press the OK button for longer than five seconds.
2. Change the parameter number digit-by-digit. If you press the OK button then the BOP-2 jumps to the next digit.
3. If you have entered all of the digits of the parameter number, press the OK button.

■ You have now entered the parameter number directly.



Entering the parameter value directly

The BOP-2 offers the option of setting the parameter value digit by digit.


Precondition

The parameter value flashes in the BOP-2 display.

Procedure

To select the parameter value directly, proceed as follows:


1. Press the OK button for longer than five seconds.
2. Change the parameter value digit-by-digit.
If you press the OK button then the BOP-2 jumps to the next digit.
3. If you have entered all of the digits of the parameter value, press the OK button.




- You have now entered the parameter value directly.

When must you not change a parameter?


The converter indicates why it currently does not permit a parameter to be changed:



You have attempted to change a read-only parameter.




You must change to basic commissioning to set this parameter.



You must turn the motor off to set this parameter.

The operating state in which you can change a parameter is provided in the List Manual for each parameter.

4.2.4.2 Changing the function of individual terminals



The function of the terminal is defined through a signal interconnection in the inverter:

- The inverter writes every input signal into a readable parameter. Parameter r0755 makes the signal of the analog input available, for example.

To define the function of the input, the appropriate parameter (connector CI or BI) must be set to the parameter number of the input.

- Every inverter output is represented by a parameter that can be written to. The value of parameter p0771 defines the analog output signal, for example.

To define the output function, you must set the parameter number of the output to the parameter number of the matching signal (binector CO or BO).

In the parameter list, the abbreviation CI, CO, BI or BO as prefix indicates as to whether the parameter is available as signal for the function of the terminal.

Defining the function of a digital input

Procedure



1 To define the function of a digital input, proceed as follows:

1. Select the function marked using a BI parameter.
2. Enter the parameter number of the required digital input 722.x into the BI parameter.



You have defined the digital input function.

Example: You want to switch on the motor using DI 2.	Setting in BOP-2:

Advanced settings

When switching over the master control of the inverter (for example, if you select default setting 7), you must select the correct index of the parameter:

- Index 0 (e.g., P840[00]) applies for the interface assignment on the left side of the macro illustration.
- Index 1 (e.g., P840[01]) applies for the interface assignment on the right side of the macro illustration.

Defining the function of an analog input

Procedure

- ➔ 1 To define the function of an analog input, proceed as follows:
- 2
1. Select the function marked using a CI parameter.
 2. Enter the parameter number of analog input 755[00] into the CI parameter.
 3. Determine whether the analog input is a current or a voltage input:
 - Set the I/U switch at the front of the inverter to the correct position.
 - Set the p0756[00] parameter to the corresponding value.

■ You have now defined the analog input function.

Example: You want to enter the supplementary setpoint via AI 0.	Setting in BOP-2:

Advanced settings

When switching over the master control of the inverter (for example, if you select default setting 7), you must select the correct index of the parameter:

- Index 0 (e.g. p1075[00]) applies to the assignment for the interface on the left-hand side of the macro representation.
- Index 1 (e.g. P1075[01]) applies to the assignment for the interface on the right-hand side of the macro representation.

Defining the function of a digital output

Procedure

- ➔ 1 To define the function of a digital output, proceed as follows:
- 2
1. Select the function marked using a BO parameter.
 2. Enter the number of the BO parameter into parameter p073x of the digital output.
- You have defined the digital output function.

Example: You want to report a "fault" signal via the DO 1.	Setting in BOP-2:

Defining the function of an analog output

Procedure



To define the function of an analog output, proceed as follows:

1. Select the function marked using a CO parameter.
2. Enter the number of the CO parameter into parameter p0771 of the analog output.
3. Use p0776[0] to determine whether the analog output is a current or voltage input.




You have now defined the analog output function.

Example: You want to output the signal for the actual current via AO 0.	Setting in BOP-2:

4.2.4.3 Releasing the failsafe function "Safe Torque Off" (STO)

Precondition



You selected an interface assignment with terminals reserved for a failsafe function. See also Default setting of the interfaces (Page 24).

Procedure



For releasing the STO function you have to set the following parameters:

1. p0010 = 95 - Enter commissioning of fail-safe functions.
2. p9761 = ... - Enter password for fail-safe function (factory setting = 0).
3. p9762 = ... - Enter new password, if required (0 ... FFFF FFFF).
4. p9763 = ... - Confirm new password.
5. p9601.0 = 1 - Select STO via terminal strip.
6. p9659 = ... - Set the forced checking procedure timer.
7. p9700 = D0 - Copy fail-safe parameters.
8. p9701 = DC - Confirm fail-safe parameters.
9. p0010 = 0 - Finish commissioning of fail-safe functions
10. p0971 = 1 - Save the parameters in a non-volatile memory
11. Wait until p0971 = 0
12. Bring the converter into a completely no-voltage condition (400V and 24V) and switch on again.



You have released the STO function.

4.2.4.4 Parameter list

The following list contains the basic parameter information with access level 1 ... 3. The complete parameter list is provided in the list manual, see Product support (Page 73).

No.	Description
Operation and visualization	
r0002	Drive operating display
p0003	Access level
p0010	Drive, commissioning parameter filter
p0015	Macro drive unit See also Default setting of the interfaces (Page 24)
r0018	Control Unit firmware version
r0020	Speed setpoint smoothed [100 % \pm p2000]
r0021	CO: Actual speed smoothed [100 % \pm p2000]
r0022	Speed actual value rpm smoothed [rpm]
r0024	Output frequency smoothed [100 % \pm p2000]
r0025	CO: Output voltage smoothed [100 % \pm p2001]
r0026	CO: DC link voltage smoothed [100 % \pm p2001]
r0027	CO: Absolute actual current smoothed [100 % \pm p2002]
r0031	Actual torque smoothed [100 % \pm p2003]
r0032	CO: Active power actual value smoothed [100 % \pm r2004]
r0034	Motor utilization [100 \pm 100%]
r0035	CO: Motor temperature [100°C \pm p2006]
r0036	CO: Power unit overload I ² t [100 \pm 100%]
r0039	Energy consumption [kWh]
	[0] Energy balance (total) [1] Energy drawn
	[2] Energy fed back
p0040	0 \rightarrow 1 Reset the energy consumption display
r0041	Energy usage saved/energy saved
r0042	CO: Process energy display
	[0] Energy balance (total) [1] Energy drawn
	[2] Energy fed back
p0043	BI: Release display of energy consumption
	0 \rightarrow 1: Start energy display r0042
p0045	Smoothing time constant, display values [ms]
r0046	CO/BO: Missing enable signals
r0047	Motor data identification routine and speed controller optimization

No.	Description
r0050	CO/BO: Command Data Set CDS effective
r0051	CO/BO: Drive Data Set DDS effective
r0052	CO/BO: Status word 1
	.00 Ready to start
	.01 Ready
	.02 Operation enabled
	.03 Fault active
	.04 Coast down active (OFF2)
	.05 Quick stop active (OFF3)
	.06 Closing lockout active
	.07 Alarm active
	.08 Deviation, setpoint/actual speed
	.09 Control requested
	.10 Maximum speed reached
	.11 I,M,P limit reached
	.12 Motor holding brake open
	.13 Alarm overtemperature motor
.14 Motor rotates forwards	
.15 Alarm inverter overload	
r0053	CO/BO: Status word 2
r0054	CO/BO: Control word 1
	.00 ON/OFF1
	.01 OFF2
	.02 OFF3
	.03 Enable ramp-function generator
	.04 Enable ramp-function generator
	.05 Continue ramp-function generator
	.06 Enable speed setpoint
	.07 Acknowledge fault
	.08 Jog bit 0
	.09 Jog bit 1
	.10 Master control by PLC
	.11 Direction reversal (setpoint)
	.13 Motorized potentiometer, raise
	.14 Motorized potentiometer, lower
.15 CDS bit 0	

No.	Description	
r0055	CO/BO: Supplementary control word	
	.00 Fixed setpoint, bit 0	
	.01 Fixed setpoint, bit 1	
	.02 Fixed setpoint, bit 2	
	.03 Fixed setpoint, bit 3	
	.04 DDS selection, bit 0	
	.05 DDS selection, bit 1	
	.08 Technology controller enable	
	.09 DC braking enable	
	.11 Droop enable	
	.12 Closed-loop torque control active	
	.13 External fault 1 (F07860)	
	.15 CDS bit 1	
	r0056	CO/BO: Status word, closed-loop control
	r0060	CO: Speed setpoint before setpoint filter [100 % \pm p2000]
r0062	CO: Speed setpoint after filter [100 % \pm p2000]	
r0063	CO: Speed actual value unsmoothed [100 % \pm p2000]	
r0064	CO: Speed controller system deviation [100 % \pm p2000]	
r0065	Slip frequency [100 % \pm p2000]	
r0066	CO: Output frequency [100 % \pm p2000]	
r0067	CO: Output current, maximum [100 % \pm p2002]	
r0068	CO: Absolute current actual value unsmoothed [100 % \pm p2002]	
r0070	CO: Actual DC link voltage [100 % \pm p2001]	
r0071	Maximum output voltage [100 % \pm p2001]	
r0072	CO: Output voltage [100 % \pm p2001]	
r0075	CO: Current setpoint field-generating [100 % \pm p2002]	
r0076	CO: Current actual value field-generating [100 % \pm p2002]	
r0077	CO: Current setpoint torque-generating [100 % \pm p2002]	
r0078	CO: Current actual value torque-generating [100 % \pm p2002]	
r0079	CO: Torque setpoint, total [100 % \pm p2003]	
r0080	CO: Actual torque value	
	[0] unsmoothed [1] smoothed	
r0082	CO: Active power actual value	
	[0] unsmoothed [1] smoothed with p0045	
	[2] Electric power	

No.	Description
Commissioning	
p0096	Application class
	0 Expert 1 Standard Drive Control 2 Dynamic Drive Control
p0100	IEC/NEMA motor standard
	0 IEC motor (50 Hz, SI units) 1 NEMA motor (60 Hz, US units)
	2 NEMA motor (60 Hz, SI units)
p0124	CU Identification via LED
p0133	Motor configuration
	.00 1: Delta 0: Star .01 1: 87 Hz 0: No 87 Hz
p0170	Number of Command Data Sets (CDS)
p0180	Number of Drive Data Sets (DDS)
Power Module	
p0201	Power unit code number
r0204	Power unit, hardware properties
p0205	Power unit application
	0 Load cycle with high overload 1 Load cycle with light overload
r0206	Rated power unit power [kw/hp]
r0207	Rated power unit current
r0208	Rated power unit line supply voltage [V]
r0209	Power unit, maximum current
p0210	Drive unit line supply voltage [V]
p0219	Braking resistor braking power [kW]
p0230	Drive filter type, motor side
	0 No filter 1 Motor reactor
	2 dv/dt filter 3 Siemens sine-wave filter
	4 Sine wave filter, third-party manufacturer
p0233	Power unit motor reactor [mH]
p0234	Power unit sine-wave filter capacitance [μ F]
r0238	Internal power unit resistance
p0287	Ground fault monitoring thresholds [100 % \pm r0209]
r0289	CO: Maximum power unit output current [100 % \pm p2002]

No.	Description	No.	Description						
p0290	Power unit overload response	p0340	Automatic calculation of motor/control parameters						
0	Reduce output current or output frequency	p0341	Motor moment of inertia [kgm ²]						
1	No reduction, shutdown when overload threshold is reached	p0342	Ratio between the total and motor moment of inertia [kgm ²]						
2	Reduce I _{output} or f _{output} and f _{pulse} (not using I _{2t}).	p0344	Motor weight (for thermal motor model) [kg]						
3	Reduce the pulse frequency (not using I _{2t})	r0345	Motor rated running-up time [s]						
12	I _{output} or f _{output} and automatic pulse frequency reduction	p0346	Motor excitation build-up time [s]						
13	Automatic pulse frequency reduction	p0347	Motor de-excitation time [s]						
p0292	Power unit temperature alarm threshold [°C]	p0350	Motor stator resistance, cold [Ω]						
p0295	Fan run-on time [s]	p0352	Cable resistance [Ω]						
Motor		r0394	Rated motor power [kW]						
p0300	Motor type selection	r0395	Actual stator resistance						
0	No motor	1	Standard induction motor	2	Synchronous motor	Technology and units			
10	1LE1	13	1LG6	17	1LA7	p0500	Technology application		
19	1LA9	100	1LE1	108	1PH8	0	Standard drive	1	Pumps and fans
271	1FG1	277	1FK7			2	Encoderless control up to f = 0	2	Pumps and fans, efficiency optimization
p0301	Motor code number selection					p0501	Technological application (Standard Drive Control)		
p0304	Rated motor voltage [V]					0	Constant load (linear characteristic)	1	Speed-dependent load (parabolic characteristic)
p0305	Rated motor current [A]					p0502	Technology application (Dynamic Drive Control)		
p0306	Number of motors connected in parallel					0	Standard drive (e.g. pump, fan)	1	Dynamic approach or reversing
p0307	Rated motor power [kW]					5	Heavy starting (e.g. extruders, compressors)		
p0308	Rated motor power factor					p0505	Selecting the system of units		
p0309	Rated motor efficiency [%]					1	SI	2	Referred/SI
p0310	Rated motor frequency [Hz]					3	US	4	Referred/US
p0311	Rated motor speed [rpm]					p0514	Specific scaling, reference values		
p0312	Rated motor torque [Nm]					p0515	Specific scaling, parameter referred to p0514[0]		
r0313	Motor pole pair number, current (or calculated)					p0516	Specific scaling, parameter referred to p0514[1]		
p0320	Motor rated magnetizing current/short-circuit current [A]						
p0322	Maximum motor speed [rpm]					p0524	Specific scaling, parameter referred to p0514[9]		
p0323	Maximum motor current [A]					p0530	Bearing, type selection		
p0325	Motor pole position identification current 1. Phase [A]					p0531	Bearing, code number selection		
p0329	Motor pole position identification current [A]					p0532	Bearing, maximum speed		
r0330	Rated motor slip					p0541	Load gear unit code number		
r0331	Actual motor magnetizing current/short-circuit current					p0542	Load gear unit maximum speed		
r0333	Rated motor torque [Nm]					p0543	Load gear unit maximum torque		
p0335	Motor cooling type					p0544	Load gear unit gear ratio (absolute value) total, numerator		

No.	Description	
p0545	Load gear unit gear ratio (absolute value) total, nominator	
p0546	Load gear unit output direction of rotation inversion	
p0550	Brake type	
p0551	Brake code number	
p0552	Brake maximum speed	
p0553	Brake holding torque	
p0554	Brake moment of inertia	
p0573	Inhibit automatic reference value calculation	
p0595	Selecting technological units	
	1 % 2 1 referred, dimensionless	
	3 bar 4 °C 5 Pa	
	6 ltr/s 7 m³/s 8 ltr/min	
	9 m³/min 10 ltr/h 11 m³/h	
	12 kg/s 13 kg/min 14 kg/h	
	15 t/min 16 t/h 17 N	
	18 kN 19 Nm 20 psi	
	21 °F 22 gallon/s 23 inch³/s	
	24 gallon/min 25 inch³/min 26 gallon/h	
	27 inch³/h 28 lb/s 29 lb/min	
	30 lb/h 31 lbf 32 lbf ft	
	33 K 34 rpm 35 parts/min	
	36 m/s 37 ft³/s 38 ft³/min	
	39 BTU/min 40 BTU/h 41 mbar	
	42 inch wg 43 ft wg 44 m wg	
	45 % r.h. 46 g/kg 47 ppm	
	p0596	Reference quantity, technological units
	Thermal motor monitoring and motor model, maximum current	
	p0601	Motor temperature sensor type
0 No sensor		
1 PTC warning & timer		
2 KTY84		
4 Bimetallic NC contact warning & timer		
p0604	Motor temperature alarm threshold [°C]	
p0605	Motor temperature fault threshold [°C]	
p0610	Motor overtemperature response	
	0 No response, alarm only, no reduction of I _{max}	
	1 Alarm with reduction of I _{max} and fault	
	2 Alarm and fault, no reduction of I _{max}	
12 Messages, no reduction of I _{max} , temperature is saved		

No.	Description
p0611	I ² t motor model thermal time constant [s]
p0612	Motor temperature model activation
	00 Activate motor temperature model 1 (I ² t) 01 Activate motor temperature model 2
	02 Activate motor temperature model 3 09 Activate motor temperature model 2 expansions
p0614	Thermal resistor adaptation reduction factor
p0615	I ² t motor model fault threshold [°C]
p0625	Motor ambient temperature [°C]
p0637	Q flux, flux gradient saturated [mH]
p0640	Current limit [A]
p0650	Motor operating hours, current [h]
p0651	Motor operating hours, maintenance interval [h]
Command sources and terminals on the Control Unit	
r0720	CU number of inputs and outputs
r0722	CO/BO: CU digital inputs, status
	.00 DI 0 (terminal 5) .01 DI 1 (terminal 6)
	.02 DI 2 (terminal 7) .03 DI 3 (terminal 8)
	.04 DI 4 (terminal 16) .05 DI 5 (terminal 17)
	.11 DI 11 (terminals 3, 4) AI 0
r0723	CO/BO: CU digital inputs, status inverted
p0724	CU digital inputs debounce time [ms]
p0730	BI: CU signal source for terminal DO 0
	NO: Terminal 19 / NC: Terminal 18
p0731	BI: CU signal source for terminal DO 1
	NO: Terminal 21
r0747	CU, digital outputs status
p0748	CU, invert digital outputs
r0751	BO: CU analog inputs status word
r0752	CO: CU analog inputs input voltage/current actual AI0 (terminals 3/4)
p0753	CU analog inputs smoothing time constant [ms]
r0755	CO: CU analog inputs actual value in percent, AI0 (terminals 3/4) [100 ± 100%]
p0756	CU analog input type (terminals 3, 4)
	0 0 V ... +10 V 1 +2 V ... +10 V
	2 0 mA ... +20 mA 3 +4 mA ... +20 mA
	4 -10 V ... +10 V 8 No sensor connected

No.	Description	No.	Description
			.00 1 = AO 0 negative
p0757	CU analog input characteristic value x1	p0795	CU digital inputs, simulation mode
p0758	CU analog input characteristic value y1 [%]	p0796	CU digital inputs, simulation mode setpoint
p0759	CU analog input characteristic value x2	p0797	CU analog inputs, simulation mode
p0760	CU analog input characteristic value y2 [%]	p0798	CU analog inputs, simulation mode setpoint
p0761	CU analog input wire break monitoring response threshold	Change over and copy data sets	
p0762	CU analog inputs wire-break monitoring deceleration time [ms]	p0802	Data transfer with memory card as source/target
p0764	CU analog inputs deadband [V]	p0803	Data transfer with device memory as source/target
p0771	CI: CU analog output signal source, AO 0 (terminals 12, 13) [100 ± 100%]	p0804	Data transfer start
r0772	CU analog output, output value currently referred	12	Transfer GSD / GSDML for PROFIBUS / PROFINET onto the memory card
p0773	CU analog outputs smoothing time constant [ms]	p0806	BI: Inhibit master control
r0774	CU analog output, output voltage/current actual [100% ± p2001]	r0807	BO: Master control active
p0775	CU analog output activate absolute value generation	p0809	Copy Command Data Set CDS
p0776	CU analog output type	p0810	BI: Command data set selection CDS bit 0
0	0 mA ... +20 mA	p0819	Copy drive data set DDS
1	0 V ... +10 V	p0820	BI: Drive data set selection DDS, bit 0
2	+4 mA ... +20 mA	p0826	Motor changeover, motor number
		r0835	CO/BO: Data set changeover status word
p0777	CU analog output characteristic value x1 [%]	r0836	CO/BO: Command data set CDS selected
p0778	CU analog output characteristic value y1 [V]	r0837	CO/BO: Drive data set DDS selected
p0779	CU analog output characteristic value x2 [%]	Sequential control system (e.g. ON/OFF1)	
p0780	CU analog output characteristic value y2 [V]	p0840	BI: ON/OFF 1
p0782	BI: CU analog output invert signal source, AO 0 (terminals 12,13)	p0844	BI: No coast down/coast down (OFF2) signal source 1
r0785	BO: CU analog outputs status word	p0845	BI: No coast down/coast down (OFF2) signal source 2
		p0848	BI: No quick stop/quick stop (OFF3) signal source 1
		p0849	BI: No quick stop/quick stop (OFF3) signal source 1
		p0852	BI: Enable operation
		p0854	BI: Master control by PLC
		p0855	BI: Unconditionally release holding brake
		p0856	BI: Enable speed controller
		p0857	Power Module monitoring time [ms]
		p0858	BI: Unconditionally close holding brake
		p0860	BI: Line contactor, feedback signal
		p0861	Line contactor, monitoring time [ms]
		r0863	CO/BO: Drive coupling status word / control word
		.00	1 = closed-loop control, operation
		.01	1 = operate line contactor

No.	Description
p0867	Power unit main contactor hold time after OFF1 [ms]
p0869	Configuration sequence control
	.00 1 = keep main contactor closed for STO
r0898	CO/BO: Control word sequence control
r0899	CO/BO: Status word sequence control
PROFIBUS, PROFIdrive	
p0918	PROFIBUS address
p0922	PROFIdrive telegram selection
	1 Standard telegram 1, PZD-2/2
	20 Standard telegram 20, PZD-2/6
	352 SIEMENS telegram 352, PZD-6/6
	353 SIEMENS telegram 353, PZD-2/2, PKW-4/4
	354 SIEMENS telegram 354, PZD-6/6, PKW-4/4
999	Free telegram configuration with BICO
Faults (Part 1)	
r0944	CO: Counter for fault buffer changes
r0945	Fault code
r0946	Fault code list
r0947	Fault number
r0948	Fault time received in milliseconds [ms]
r0949	Fault value
p0952	Fault cases, counter
r0963	PROFIBUS baud rate
r0964	Device identification
p0965	PROFIdrive profile number
p0969	System runtime relative [ms]
Restoring the factory setting Saving parameters	
p0970	Reset drive parameters
	0 Inactive 1 Reset parameters except for Safety
	5 Reset safety parameters 10 Load setting 10
	11 Load setting 11 12 Load setting 12
	100 Reset BICO interconnections
p0971	Save parameters
	0 Inactive
	1 Save in nonvolatile storage (RAM → ROM)
	10 Save in a non-volatile memory as setting 10
	11 Save in a non-volatile memory as setting 11
	12 Save in a non-volatile memory as setting 12
p0972	Drive unit reset
Setpoint channel	
p1000	Speed setpoint selection
p1001	CO: Fixed speed setpoint 1 [rpm]
p1002	CO: Fixed speed setpoint 2 [rpm]
...	...
p1015	CO: Fixed speed setpoint 15 [rpm]
p1016	Fixed speed setpoint mode
	1 Direct selection 2 Selection, binary coded
p1020	BI: Fixed speed setpoint selection bit 0
p1021	BI: Fixed speed setpoint selection bit 1
p1022	BI: Fixed speed setpoint selection bit 2
p1023	BI: Fixed speed setpoint selection bit 3
r1024	CO: Fixed speed setpoint effective [100 % ± p2000]
r1025	BO: Fixed speed setpoint status
	.00 Fixed speed setpoint selected
p1030	Motorized potentiometer configuration
	00 Storage active
	01 Automatic operation, ramp-function generator active
	02 Initial rounding active
	03 Storage in NVRAM active
p1035	BI: Motorized potentiometer setpoint raise
p1036	BI: Motorized potentiometer setpoint lower
p1037	Motorized potentiometer maximum speed [rpm]
p1038	Motorized potentiometer minimum speed [rpm]
p1040	Motorized potentiometer start value [rpm]
p1043	BI: Motorized potentiometer, accept setting value
p1044	CI: Motorized potentiometer setting value [100 % ± p2000]
r1045	CO: Motorized potentiometer, setpoint in front of the ramp-function generator [rpm]
p1047	Motorized potentiometer ramp-up time [s]
p1048	Motorized potentiometer ramp-down time [s]
r1050	CO: Motorized potentiometer setpoint after the ramp-function generator [100 % ± p2000]

p1055	Bl: Jog bit 0
p1056	Bl: Jog bit 1
p1058	Jog 1 speed setpoint [rpm]
p1059	Jog 2 speed setpoint [rpm]
p1070	Cl: Main setpoint [100 % \pm p2000]
p1071	Cl: Main setpoint scaling [100 \pm 100%]
r1073	CO: Main setpoint effective [100 % \pm p2000]
p1075	Cl: Supplementary setpoint [100 % \pm p2000]
p1076	Cl: Supplementary setpoint scaling [100 \pm 100%]
r1077	CO: Supplementary setpoint effective [100 % \pm p2000]
r1078	CO: Total setpoint effective [100 % \pm p2000]
p1080	Minimum speed [rpm]
p1081	Maximum speed scaling [%]
p1082	Maximum speed [rpm]
p1083	CO: Speed limit in positive direction of rotation [rpm]
r1084	CO: Speed limit positive effective [100 % \pm p2000]
p1086	CO: Speed limit in negative direction of rotation [rpm]
r1087	CO: Speed limit negative effective [100 % \pm p2000]
p1091	Skip speed 1 [rpm]
p1092	Skip speed 2 [rpm]
p1101	Skip speed bandwidth [rpm]
p1106	Cl: Minimum speed signal source
p1110	Bl: Inhibit negative direction
p1111	Bl: Inhibit positive direction
p1113	Bl: Setpoint inversion
r1114	CO: Setpoint after the direction limiting [100 % \pm p2000]
r1119	CO: Ramp-function generator setpoint at the input [100 % \pm p2000]
p1120	Ramp-function generator ramp-up time [s]
p1121	Ramp-function generator ramp-down time [s]
p1130	Ramp-function generator initial rounding-off time [s]
p1131	Ramp-function generator final rounding-off time [s]
p1134	Ramp-function generator rounding-off type
0	Continuous smoothing
1	Discontinuous smoothing
p1135	OFF3 ramp-down time [s]
p1136	OFF3 initial rounding-off time [s]
p1137	OFF3 final rounding-off time [s]
p1138	Cl: Acceleration ramp scaling [100 \pm 100%]
p1139	Cl: Ramp down scaling [100 \pm 100%]
p1140	Bl: Enable ramp-function generator
p1141	Bl: Continue ramp-function generator
p1142	Bl: Enable speed setpoint
r1149	CO: Ramp-function generator acceleration [100 % \pm p2007]
r1170	CO: Speed controller setpoint sum [100 % \pm p2000]
r1198	CO/BO: Control word, setpoint channel
Functions (e.g. motor holding brake)	
p1200	Flying restart operating mode
0	Flying restart inactive
1	Flying restart always active (start in setpoint direction)
4	Flying restart always active (start only in setpoint direction)
p1201	Bl: Flying restart enable signal source
p1202	Flying restart search current [100 % \pm r0331]
p1203	Flying restart search rate factor [%] A higher value results in a longer search time.
p1206	Set fault number without automatic restart
p1210	Automatic restart mode
0	Inhibit automatic restart
1	Acknowledge all faults without restarting
4	Restart after line supply failure, without additional start attempts
6	Restart after fault with additional start attempts
14	Restart after line supply failure following manual acknowledgement
16	Restart after fault following manual acknowledgement
26	Acknowledging all faults and restarting for an ON command
p1211	Automatic restart, start attempts
p1212	Automatic restart, delay time start attempts [s]
p1213	Automatic restart, monitoring time [s]
[0]	Restart
[1]	Reset start counter

p1215	Motor holding brake configuration		p1257	V_{DC_min} controller speed threshold [rpm]
	0	No motor holding brake being used	r1258	CO: V_{DC} controller output
	3	Motor holding brake like sequential control, connection via BICO	p1271	Flying restart maximum frequency for the inhibited direction [Hz]
p1216	Motor holding brake, opening time [ms]		p1280	V_{DC} controller or V_{DC} monitoring configuration (V/f)
p1217	Motor holding brake, closing time [ms]		0	Inhibit V_{DC} controller
p1226	Standstill detection threshold [rpm]		1	Enable V_{DC_max} controller
p1227	Standstill detection monitoring time [s]		p1281	Vdc controller configuration
p1230	BI: DC braking activation		r1282	V_{DC_max} controller switch-in level (V/f) [100 % \pm p2001]
p1231	DC braking configuration		p1283	V_{DC_max} controller dynamic factor (V/f) [%]
	0	No function	p1284	V_{DC_max} controller time threshold (U/f) [s]
	4	DC braking	p1288	V_{DC_max} controller ramp-function generator feedback factor (U/f)
	5	DC braking OFF1/OFF3	p1290	V_{DC} controller proportional gain (U/f)
	14	DC braking below starting speed	p1291	V_{DC} controller integral time (U/f) [ms]
p1232	DC braking, braking current [A]		p1292	V_{DC} controller rate time (U/f) [ms]
p1233	DC braking time [s]		p1297	V_{DC_min} controller speed threshold (U/f) [rpm]
p1234	Speed at the start of DC braking [rpm]		V/f control	
r1239	CO/BO: DC braking status word		p1300	Open-loop/closed-loop control operating mode
p1240	V_{DC} controller or V_{DC} monitoring configuration (vector control)		0	V/f control with linear characteristic
	0	Inhibit V_{DC} controller	1	V/f control with linear characteristic and FCC
	1	Enable V_{DC_max} controller	2	V/f control with parabolic characteristic
	2	Enable V_{DC_min} controller (kinetic buffering)	3	V/f control with parameterizable characteristic
	3	Enable V_{DC_min} controller and V_{DC_max} controller	4	V/f control with linear characteristic and ECO
r1242	V_{DC_max} controller switch-in level [100 % \pm p2001]		5	V/f control for drive requiring a precise frequency (e.g. textiles)
p1243	V_{DC_max} controller dynamic factor [%]		6	V/f control for drive requiring a precise frequency and FCC
p1245	V_{DC_min} controller switch-in level (kinetic buffering) [%]		7	V/f control for parabolic characteristic and ECO
r1246	V_{DC_min} controller switch-in level (kinetic buffering) [100 % \pm p2001]		19	V/f control with independent voltage setpoint
p1247	V_{DC_min} controller dynamic factor (kinetic buffering) [%]		20	Speed control (without encoder)
p1249	V_{DC_max} controller speed threshold [rpm]		<p>The diagram illustrates the V/f control characteristic. The vertical axis represents voltage U and the horizontal axis represents frequency f. A dashed horizontal line indicates the maximum voltage U_n, and a dashed vertical line indicates the maximum frequency f_n. Three curves are shown: P1310 is a linear ramp; P1311 is a parabolic curve; P1312 is a parameterizable curve that starts with a higher voltage at low frequencies and follows a similar path to the linear curve.</p>	
p1250	V_{DC} controller proportional gain			
p1251	V_{DC} controller integral time [ms]			
p1252	V_{DC} controller rate time [ms]			
p1254	V_{DC_max} controller automatic ON level detection			
	0	Automatic detection inhibited		
	1	Automatic detection enabled		
p1255	V_{DC_min} controller time threshold [s]			
p1256	V_{DC_min} controller response (kinetic buffering)			
	0	Buffer V_{DC} until undervoltage, $n < p1257 \rightarrow F07405$		
	1	Buffer V_{DC} until undervoltage, $n < p1257 \rightarrow F07405$, $t > p1255 \rightarrow F07406$		

p1302	V/f control configuration	
p1310	Starting current (voltage boost) permanent [100 % \pm p0305]	
p1311	Starting current (voltage boost) acceleration [%]	
p1312	Starting current (voltage boost) when starting [%]	
r1315	Voltage boost, total [100 % \pm p2001]	
p1320	U/f control programmable frequency f [Hz] and voltage U [V] characteristic	
...		
p1327		
p1330	CI: V/f control independent voltage setpoint [100 % \pm p2001]	
p1331	Voltage limiting [V]	
p1333	U/f control FCC starting frequency [Hz]	
p1334	V/f control slip compensation starting frequency [Hz]	
p1335	Slip compensation, scaling [100 % \pm r0330]	
p1336	Slip compensation limit value [100 % \pm r0330]	
r1337	CO: Actual slip compensation [100 \pm 100%]	
p1338	V/f mode resonance damping gain	
p1340	I_{max} frequency controller proportional gain	
r1343	CO: I_{max} controller frequency output [100 % \pm p2000]	
p1349	U/f mode resonance damping maximum frequency [Hz]	
p1351	CO: Motor holding brake starting frequency [100 \pm 100%]	
p1352	CI: Motor holding brake starting frequency [100 \pm 100%]	
Closed-loop speed control		
p1400	Speed control configuration	
	.00	1 = automatic Kp/Tn adaptation active
	.01	1 = sensorless vector control, freeze I action
	.05	1 = Kp/Tn adaptation active
	.06	1 = free Tn adaptation active
	.14	1 = torque precontrol is always active 0 = torque precontrol is active when speed controller enabled
	.15	1 = sensorless vector control, speed precontrol active
	.16	1 = release I action for limitation 0 = block I action for limitation
	.18	1 = moment of inertia estimator active
	.20	1 = acceleration model is switched on
	.22	1 = obtain moment of inertia estimator value for pulse inhibit
	.24	1 = moment of inertia estimator actively accelerates the motor
r1438	CO: Speed controller speed setpoint [100 % \pm p2000]	
p1452	Speed controller speed actual value smoothing time (SLVC) [ms]	
p1470	Speed controller encoderless operation P gain	
p1472	Speed controller sensorless operation integral time [ms]	
p1475	CI: Speed controller torque setting value for motor holding brake [100 % \pm p2003]	
r1482	CO: Speed controller I torque output [100 % \pm p2003]	
r1493	CO: Total moment of inertia [kgm ²]	
p1496	Acceleration pre-control scaling [%]	
p1498	Load moment of inertia [kgm ²]	
p1502	BI: Freezing the moment of inertia estimator	
	0 = moment of inertia estimator active 1 = determined moment of inertia is frozen	
p1511	CI: Supplementary torque 1 [100 % \pm p2003]	
p1512	CI: Supplementary torque 1 scaling	
r1516	CO: Supplementary torque and acceleration torque [100 % \pm p2003]	
p1520	CO: Torque limit upper [Nm]	
p1521	CO: Torque limit lower [Nm]	
p1522	CI: Torque limit upper [100 % \pm p2003]	
p1523	CI: Torque limit lower [100 % \pm p2003]	
p1524	CO: Torque limit upper/motoring scaling [100 \pm 100%]	
p1525	CO: Torque limit lower scaling [100 \pm 100%]	
r1526	CO: Torque limit upper without offset [100 % \pm p2003]	
r1527	CO: Torque limit lower without offset [100 % \pm p2003]	

p1530	Power limit motoring [kW]	p1755	Motor model changeover speed encoderless operation [rpm]		
p1531	Power limit regenerative [kW]	p1780	Motor model adaptation configuration		
r1538	CO: Upper effective torque limit [100 % \pm p2003]	Gating unit			
r1539	CO: Lower effective torque limit [100 % \pm p2003]	p1800	Pulse frequency setpoint [kHz]		
r1547	CO: Torque limit for speed controller output	r1801	CO: Pulse frequency [100 % \pm p2000]		
	[0] Upper limit [100 % \pm p2003]	p1806	Filter time constant V _{DC} correction [ms]		
	[1] Lower limit [100 % \pm p2003]	p1820	Reverse the output phase sequence		
p1552	CI: Torque limit upper scaling without offset [100 \pm 100%]		0 Off 1 On		
p1554	CI: Torque limit lower scaling without offset [100 \pm 100%]	r1838	CO/BO: Gating unit status word 1		
p1560	Moment of inertia estimator, accelerating torque threshold value [100% \pm r0333]	Motor identification			
p1561	Moment of inertia estimator change time inertia [ms]	p1900	Motor data identification and rotating measurement		
p1562	Moment of inertia estimator change time load [ms]		0 Inhibited		
p1563	CO: Moment of inertia estimator load torque positive direction of rotation [Nm]		1 Identify the motor data at standstill and with the motor rotating		
p1564	CO: Moment of inertia estimator load torque negative direction of rotation [Nm]		2 Identify motor data at standstill		
p1570	CO: Flux setpoint [100 \pm 100%]		3 Identify motor data with the motor rotating		
p1580	Efficiency optimization [%]		11 Identify motor data and optimize the speed controller, operation		
r1598	CO: Flux setpoint total [100 \pm 100%]		12 Identify motor data (at standstill), operation		
p1610	Torque setpoint static (SLVC) [100 % \pm r0333]	p1901	Test pulse evaluation configuration		
p1611	Supplementary accelerating torque (SLVC) [100 % \pm r0333]	p1909	Motor data identification control word		
p1616	Current setpoint smoothing time [ms]	p1910	Motor data identification selection		
r1732	CO: Direct-axis voltage setpoint [100 % \pm p2001]	p1959	Rotating measurement configuration		
r1733	CO: Quadrature-axis voltage setpoint [100 % \pm p2001]	p1960	Rotating measurement selection		
p1740	Gain resonance damping with sensorless control		0 Inhibited		
p1745	Motor model error threshold stall detection [%]		1 Rotating measurement in encoderless operation		
p1750	Motor model configuration		3 Speed controller optimization in encoderless operation		
	.00	1 = forces open-loop speed-controlled starting	p1961	Saturation characteristic speed to determine [%]	
	.01	1 = forces open-loop-controlled crossing of frequency zero	p1965	Speed_ctrl_opt speed [100 % \pm p0310]	
	.02	1 = drive remains completely under closed-loop control even at frequency zero	p1967	Speed_ctrl_opt dynamic factor [%]	
	.03	1 = motor model evaluates saturation characteristic	p1980	PolID procedure	
	.06	1 = when motor is blocked, sensorless vector control remains under closed-loop speed control		1	Voltage pulsing 1st harmonic
	.07	1 = use of robust switchover limits for model switchover (open/closed-loop) during generating operation		4	Voltage pulsing, 2-phase
		6		Voltage pulsing, 2-phase inverse	
		8	Voltage pulsing 2nd harmonic, inverted		
		10	Impressing DC current		

Reference values			
p2000	Reference speed reference frequency [rpm]		
p2001	Reference voltage [V]		
p2002	Reference current [A]		
p2003	Reference torque [Nm]		
r2004	Reference power		
p2006	Reference temperature [°C]		
p2010	Commissioning interface baud rate		
p2011	Commissioning interface address		
p2016	CI: Comm IF USS PZD send word		
USS or Modbus RTU			
p2020	Fieldbus interface baud rate		
	4	2400 baud	5 4800 baud
	6	9600 baud	7 19200 baud
	8	38400 baud	9 57600 baud
	10	76800 baud	11 93750 baud
	12	115200 baud	13 187500 baud
p2021	Fieldbus interface address		
p2022	Fieldbus interface USS PZD number		
p2023	Fieldbus interface USS PKW number		
	0	PKW 0 words	3 PKW 3 words
	4	PKW 4 words	127 PKW variable
p2024	Fieldbus interface times [ms]		
	[0]	Maximum processing time	
	[1]	Character delay time	
	[2]	Telegram pause time	
r2029	Fieldbus interface error statistics		
	[0]	Number of error-free telegrams	
	[1]	Number of rejected telegrams	
	[2]	Number of framing errors	
	[3]	Number of overrun errors	
	[4]	Number of parity errors	
	[5]	Number of starting character errors	
	[6]	Number of checksum errors	
	[7]	Number of length errors	
p2030	Fieldbus interface protocol selection		
	0	No protocol	1 USS
	2	MODBUS	3 PROFIBUS
	4	CAN	7 PROFINET
	10	Ethernet/IP	
p2031	Fieldbus interface Modbus parity		
	0	No parity	1 Odd parity
	2	Even parity	
r2032	Master control, control word effective		
	.00	ON / OFF1	
	.01	OFF2 inactive	
	.02	OFF3 inactive	
	.03	Enable operation	
	.04	Enable ramp-function generator	
	.05	Start ramp-function generator	
	.06	Enable speed setpoint	
	.07	Acknowledge fault	
	.08	Jog bit 0	
	.09	Jog bit 1	
	.10	Master control by PLC	
p2037	PROFIdrive STW1.10 = 0 mode		
	0	Freeze setpoints and further process sign-of-life	
	1	Freeze setpoints and sign-of-life	
	2	Setpoints are not frozen	
p2038	PROFIdrive STW/ZSW interface mode		
	0	SINAMICS	
	2	VIK-NAMUR	
p2040	Fieldbus interface monitoring time [ms]		
PROFIBUS, PROFIdrive			
p2042	PROFIBUS ID Number		
	0	SINAMICS	2 VIK-NAMUR
r2043	BO: PROFIdrive PZD state		
	.00	1 = setpoint failure	.02 1 = fieldbus running
p2044	PROFIdrive fault delay [s]		
p2047	PROFIBUS additional monitoring time [ms]		
r2050	CO: PROFIdrive PZD receive word		
	[0]	PZD 1 ...	[7] PZD 8
p2051	CI: PROFIdrive PZD send word		
	[0]	PZD 1 ...	[7] PZD 8
r2053	PROFIdrive diagnostics send PZD word		
	[0]	PZD 1 ...	[7] PZD 8
r2054	PROFIBUS status		
	0	Off	
	1	No connection (search for baud rate)	
	2	Connection OK (baud rate found)	
	3	Cyclic connection with master (data exchange)	
	4	Cyclic data OK	

r2055	PROFIBUS diagnosis standard			
	[0]	Master bus address		
	[1]	Master input total length bytes		
	[2]	Master output total length bytes		
r2057	PROFIBUS address switch diagnostics			
r2060	CO: IF1 PROFIdrive PZD receive double word			
	[0]	PZD 1 + 2 ...	[10]	PZD 11 + 12
r2061	CI: IF1 PROFIdrive PZD send double word			
	[0]	PZD 1 + 2 ...	[10]	PZD 11 + 12
r2063	IF1 PROFIdrive diagnostics PZD send double word			
	[0]	PZD 1 + 2 ...	[10]	PZD 11 + 12
r2067	IF1 PZD maximum interconnected			
	[0]	Receiving	[1]	Sending
p2072	Response, receive value after PZD failure			
	.00	Unconditionally open holding brake (p0855)	1 = freeze value	
			0 = zero value	
r2074	PROFIdrive diagnostics bus address PZD receive			
	[0]	PZD 1 ...	[7]	PZD 8
r2075	PROFIdrive diagnostics telegram offset PZD receive			
	[0]	PZD 1 ...	[7]	PZD 8
r2076	PROFIdrive diagnostics telegram offset PZD send			
	[0]	PZD 1 ...	[7]	PZD 8
r2077	PROFIBUS diagnostics peer-to-peer data transfer addresses			
p2079	PROFIdrive PZD telegram selection extended			
	See p0922			
p2080	BI: Binector-connector converter, status word 1			
	The individual bits are combined to form status word 1.			
p2088	Binector-connector converter, invert status word			
r2089	CO: Send binector-connector converter status word			
	[0]	Status word 1		
	[1]	Status word 2		
	[2]	Free status word 3		
	[3]	Free status word 4		
	[4]	Free status word 5		
r2090	BO: PROFIdrive PZD1 receive bit-serial			
r2091	BO: PROFIdrive PZD2 receive bit-serial			
r2092	BO: PROFIdrive PZD3 receive bit-serial			
r2093	BO: PROFIdrive PZD4 receive bit-serial			
r2094	BO: Connector-binector converter binector output			
r2095	BO: Connector-binector converter binector output			
p2098	Invert connector-binector converter binector output			
p2099	CI: Connector-binector converter signal source			
Faults (Part 2) and alarms				
p2100	Setting the fault number for fault response			
p2101	Setting the fault response			
	0	None	1	OFF1
	2	OFF2	3	OFF3
	5	STOP2	6	DC braking
p2103	BI: 1. Acknowledge faults			
p2104	BI: 2. Acknowledge faults			
p2106	BI: External fault 1			
r2110	Alarm number			
p2111	Alarm counter			
p2112	BI: External alarm 1			
p2118	Change message type, message number			
p2119	Change message type, type			
	1	Fault	2	Alarm
	3	No message		
r2122	Alarm code			
r2123	Alarm time received [ms]			
r2124	Alarm value			
r2125	Alarm time removed [ms]			
p2126	Setting fault number for acknowledge mode			
p2127	Sets acknowledgement mode			
p2128	Selecting fault/alarm code for trigger			
r2129	CO/BO: Trigger word for faults and alarms			
r2130	Fault time received in days			
r2131	CO: Actual fault code			
r2132	CO: Actual alarm code			
r2133	Fault value for float values			
r2134	Alarm value for float values			
r2135	CO/BO: Status word faults / alarms 2			
r2136	Fault time removed in days			
r2138	CO/BO: Control word, faults/alarms			
r2139	CO/BO: Status word, faults/alarms 1			
p2141	Speed threshold value 1 [rpm]			
p2153	Speed actual value filter time constant [ms]			
p2155	Speed threshold value 2 [rpm]			
p2156	Switch-on delay comparison value reached [ms]			
p2165	Load monitoring blocking monitoring upper threshold [rpm]			
p2168	Load monitoring blocking monitoring torque threshold [Nm]			

r2169	CO: Speed actual value smoothed signals [rpm]	p2240	Techn. controller motorized potentiometer start value [%]			
p2170	Current threshold value [A]	r2245	CO: Techn. controller motorized potentiometer setpoint before RFG [100 ± 100%]			
p2171	Current threshold value reached delay time [ms]	p2247	Techn. controller motorized potentiometer ramp-up time [s]			
p2172	DC-link voltage threshold [V]	p2248	Techn. controller motorized potentiometer ramp-down time [s]			
p2174	Torque threshold value 1 [Nm]	r2250	CO: Techn. controller motorized potentiometer setpoint after RFG [100 ± 100%]			
p2191	Load monitoring torque threshold without load [Nm]	p2251	Techn. controller mode			
p2194	Torque threshold value 2 [%]		0	Techn. controller as main speed setpoint		
p2195	Torque utilization switch-off delay [ms]		1	Techn. controller as additional speed setpoint		
r2197	CO/BO: Status word monitoring functions 1	p2252	Technology controller configuration			
r2198	CO/BO: Status word monitoring 2		.04	1 = ramp function generator (up/down) bypass deactivated		
r2199	CO/BO: Status word monitoring 3		.05	1 = integrator for skip speeds active		
Technology controller			.06	1 = do not display internal controller limitation		
p2200	BI: Technology controller enable	p2253	CI: Techn. controller setpoint 1 [100 ± 100%]			
p2201	CO: Techn. controller fixed value 1 [100 ± 100%]	p2254	CI: Techn. controller setpoint 2 [100 ± 100%]			
p2202	CO: Techn. controller fixed value 2 [100 ± 100%]	p2255	Techn. controller setpoint 1 scaling [100 ± 100%]			
...	...	p2256	Techn. controller setpoint 2 scaling [100 ± 100%]			
p2215	CO: Techn. controller fixed value 15 [100 ± 100%]	p2257	Techn. controller ramp-up time [s]			
p2216	Techn. controller fixed value selection method	p2258	Techn. controller ramp-down time [s]			
	0 Selection, direct 1 Selection, binary	r2260	CO: Techn. controller setpoint after ramp function generator [100 ± 100%]			
p2220	BI: Techn. controller fixed value selection bit 0	p2261	Techn. controller setpoint filter time constant [s]			
p2221	BI: Techn. controller fixed value selection bit 1	p2263	Techn. controller type			
p2222	BI: Techn. controller fixed value selection bit 2		0	D component in the actual value signal		
p2223	BI: Techn. controller fixed value selection bit 3		1	D component in the fault signal		
r2224	CO: Techn. controller fixed value active [100 ± 100%]	p2264	CI: Techn. controller actual value [100 ± 100%]			
r2225	CO/BO: Techn. controller fixed value selection status word	p2265	Techn. controller actual value filter time constant [s]			
r2229	Techn. controller number currently	r2266	CO: Techn. controller actual value after filter [100 ± 100%]			
p2230	Techn. controller motorized potentiometer configuration	p2267	Techn. controller upper limit actual value [100 ± 100%]			
	.00 Storage active	p2268	Techn. controller lower limit actual value [100 ± 100%]			
	.02 Initial rounding active	p2269	Techn. controller gain actual value [%]			
	.03 Non-volatile data save active for p2230.0 = 1	p2270	Techn. controller actual value function selection			
	.04 Ramp-function generator always active		0	No function	1	√x
r2231	Techn. controller motorized potentiometer setpoint memory		2	x ²	3	x ³
p2235	BI: Techn. controller motorized potentiometer setpoint up					
p2236	BI: Techn. controller motorized potentiometer setpoint down					
p2237	Techn. controller motorized potentiometer maximum value [%]					
p2238	Techn. controller motorized potentiometer minimum value [%]					

p2271	Techn. controller actual value inversion (sensor type)			
	0	No inversion		
	1	Inversion of the technology controller actual value signal		
r2272	CO: Techn. controller actual value scaled [100 ± 100%]			
r2273	CO: Techn. controller error [100 ± 100%]			
p2274	Techn. controller actual differentiation time constant [s]			
p2280	Techn. controller proportional gain			
p2285	Techn. controller integral time [s]			
p2286	BI: Hold techn. controller integrator			
p2289	CI: Techn. controller pre-control signal [100 ± 100%]			
p2290	BI: Technology controller limitation enable			
	1 = enable technology controller output			
p2291	CO: Techn. controller maximum limit [100 ± 100%]			
p2292	CO: Techn. controller minimum limit [100 ± 100%]			
p2293	Techn. controller ramp-up/ramp-down time [s]			
r2294	CO: Techn. controller output signal [100 ± 100%]			
p2295	CO: Techn. controller output scaling [100 ± 100%]			
p2296	CI: Techn. controller output scaling [100 ± 100%]			
p2297	CI: Techn. controller maximum limit signal source [100 ± 100%]			
p2298	CI: Techn. controller minimum limit signal source [100 ± 100%]			
p2299	CI: Techn. controller limit offset [100 ± 100%]			
p2302	Techn. controller output signal start value [%]			
p2306	Techn. controller fault signal inversion			
	0	No inversion	1	Inversion of the fault signal
p2339	Techn. controller threshold value for I action stop at skip speed [%]			
r2344	CO: Techn. controller last speed setpoint (smoothed) [100 ± 100%]			
p2345	Techn. controller fault response			
	0	Function inhibited		
	1	For a fault: change over to r2344 (or p2302)		
	2	For a fault: Change over to p2215		
r2349	CO/BO: Techn. controller status word			
p2350	PID Autotune Enable			
	0	No function	1	Ziegler Nichols
	2	Slight overshoot	3	No overshoot
	4	Optimize P and I action of the technology controller only		
p2354	PID tuning timeout length			
p2355	PID tuning offset			
p2900	CO: Fixed value 1 [100 ± 100%]			
p2901	CO: Fixed value 2 [100 ± 100%]			
r2902	CO: Fixed values [100 ± 100%]			
p2930	CO: Fixed value M [Nm]			
r2969	Direct axis flux model display			
Messages				
r3113	CO/BO: NAMUR message bit bar			
p3117	Change safety message type			
	0	Safety messages are not reparameterized		
	1	Safety messages are reparameterized		
r3120	Component fault			
	0	No assignment	1	Control Unit
	2	Power Module	3	Motor
r3121	Component alarm			
	0	No assignment	1	Control Unit
	2	Power Module	3	Motor
r3122	Diagnostic attribute fault			
r3123	Diagnostic attribute alarm			
p3233	Torque actual value filter time constant [ms]			
Energy-saving display				
p3320	Fluid flow machine P = f(n), Y coordinate: P flow 1%, point 1			
p3321	Fluid flow machine P = f(n), X coordinate: n flow 1%, point 1			
p3322	P = f(n), Y coordinate: P flow 2%, point 2			
p3323	P = f(n), X coordinate: n flow 2%, point 2			
...	...			
p3328	P = f(n), Y coordinate: P flow 5%, point 5			
p3329	P = f(n), X coordinate: n flow 5%, point 5			
Two/three wire control				
p3330	BI: 2-3 wire control 1			
p3331	BI: 2-3 wire control 2			
p3332	BI: 2-3 wire control 3			
r3333	CO/BO: 2-3 wire output			
	.00	2-3 wire ON		
	.01	2-3 wire reverse		
	.02	2-3 wire ON / invert		
	.03	2-3 wire reverse/invert		

Friction characteristic				
p3820	Friction characteristic, value n0			
p3821	Friction characteristic, value n1			
...	...			
p3829	Friction characteristic, value n9			
p3830	Friction characteristic, value M0			
p3831	Friction characteristic, value M1			
...	...			
p3839	Friction characteristic, value M9			
r3840	CO/BO: Friction characteristic status word			
	.00	1 = Friction characteristic OK	.01	1 = Recording of the friction characteristic activated
	.02	1 = Recording of the friction characteristic ended	.03	1 = Recording of the friction characteristic aborted
	.08	1 = Friction characteristic positive direction		
r3841	CO: Friction characteristic, output [Nm]			
p3842	Activate friction characteristic			
	1	Friction characteristic active		
p3845	Activate friction characteristic plot			
	0	Recording of friction characteristic plot deactivated		
	1	Recording of friction characteristic in all directions		
	2	Recording of friction characteristic in positive direction only		
3	Recording of friction characteristic in negative direction only			
p3846	Friction characteristic plot ramp-up/ramp-down time [s]			
p3847	Friction characteristic plot warm-up period [s]			
Compound braking				
p3856	Compound braking current [100 ± 100%]			
r3859	CO/BO: Compound braking status word			
Administration parameters				
p3900	Completion of quick commissioning			
r3925	Identification final display			
p3950	Service parameters			
p3981	Faults, acknowledge drive object			
p3985	Master control mode selection			
r3996	Parameter write inhibit status			
p5271	Online tuning controller configuration			
p5310	Moment of inertia precontrol configuration			
r5311	Moment of inertia precontrol status word			
p5312	Moment of inertia precontrol linear positive [s ²]			
p5313	Moment of inertia precontrol constant positive [kgms ²]			
p5314	Moment of inertia precontrol linear negative [s ²]			
p5315	Moment of inertia precontrol constant negative [kgms ²]			
p5316	Moment of inertia precontrol change time moment of inertia [ms]			
p5397	Mot_temp_mod 3 ambient air temperature image p0613 [°C]			
r5398	Mot_temp_mod 3 alarm threshold image p5390 [°C]			
r5399	Mot_temp_mod 3 fault threshold image p5391 [°C]			
r5600	Pe hibernation ID			
p5602	Pe hibernation pause time, minimum [s]			
p5606	Pe hibernation duration, maximum [ms]			
p5611	Pe energy-saving properties, general			
	.00	Inhibit PROFenergy	.01	Drive triggers OFF1
.02	Transition to hibernation from PROFdrive state 4 possible			
p5612	Pe energy-saving properties, mode-dependent			
r5613	CO/BO: Pe energy-saving active/inactive			
p5614	BI: Set Pe Switching On Inhibited signal source			
r7758	Know-how protection Control Unit serial number			
r7759	Know-how protection Control Unit reference serial number			
p7760	Write protection/know-how protection status			
	.00	1 = Write protection active		
	.01	1 = Know-how protection active		
	.02	1 = Know-how protection temporarily unlocked		
	.03	1 = Know-how protection cannot be deactivated		
	.04	1 = Memory card copy protection active		
.05	1 = basis copy protection active			
.06	1 = trace and measuring functions for diagnostic purposes active			
p7761	Write protection			
	0	Not active	1	Active

p7762	Write access for control using multi-master third-party bus system					
	0	Free write access independent of p7761				
	1	No free write access (p7761 is active)				
p7763	Know-how protection OEM exception list number of parameters					
p7764	Know-how protection OEM exception list					
p7765	Know-how protection memory card copy protection					
	.00	1 = extended copy protection - linked to memory card and CU				
	.01	1 = basic copy protection active - linked to memory card				
	.02	1 = trace and measuring functions permitted for diagnostic purposes				
p7766	Know-how protection password input					
p7767	Know-how protection password new					
p7768	Know-how protection password confirmation					
p7769	Know-how protection memory card setpoint serial number					
p7775	NVRAM data action					
r7843	Memory card serial number					
r8540	BO: STW1 from BOP/IOP in manual mode					
r8541	CO: Speed setpoint from BOP/IOP in manual mode					
p8542	BI: Active STW1 in BOP/IOP manual mode					
p8543	CI: Active speed setpoint in BOP/IOP manual mode					
p8552	IOP speed unit					
p8558	BI: Selection IOP manual mode					
r8570	Macro Drive object Display of the macro files stored in the inverter. See also p0015.					
CANopen						
r8600	CAN Device Type					
r8601	CAN Error Register					
p8602	CAN SYNC-Object					
p8603	CAN COB-ID Emergency Message [hex]					
p8604	CAN Node Guarding					
p8606	CAN Producer Heartbeat Time [ms]					
r8607	CAN Identity Object					
p8608	CAN Clear Bus Off Error					
p8609	CAN Error Behavior					
r8610	CAN First Server SDO					
p8611	CAN Pre-defined Error Field [hex]					
p8620	CAN Node-ID					
r8621	CAN Node-ID effective					
p8622	CAN bit rate [kBit/s]					
	0	1000	1	800	2	500
	3	250	4	125	5	50
	6	20	7	10		
p8623	CAN Bit Timing selection [hex]					
p8630	CAN virtual objects					
p8641	CAN Abort Connection Option Code					
	0	No response		1	OFF1	
	2	OFF2		3	OFF3	
r8680	CAN Diagnosis Hardware					
p8684	CAN NMT state after booting					
p8685	CAN NMT state					
p8699	CAN RPDO monitoring time [ms]					
p8700	CAN Receive PDO 1 [hex]					
p8701	CAN Receive PDO 2 [hex]					
...	...					
p8707	CAN Receive PDO 8 [hex]					
p8710	CAN Receive Mapping for RPDO 1 [hex]					
p8711	CAN Receive Mapping for RPDO 2 [hex]					
...	...					
p8717	CAN Receive Mapping for RPDO 8 [hex]					
p8720	CAN Transmit PDO 1 [hex]					
p8721	CAN Transmit PDO 2 [hex]					
...	...					
p8727	CAN Transmit PDO 8 [hex]					
p8730	CAN Transmit Mapping for TPDO 1 [hex]					
p8731	CAN Transmit Mapping for TPDO 2 [hex]					
...	...					
p8737	CAN Transmit Mapping for TPDO 8 [hex]					
p8744	CAN PDO Mapping Configuration					
	1:	Predefined connection set				
	2:	Free PDO mapping				
r8745	CO: CAN free PZD receive objects 16 bit					
p8746	CI: CAN free PZD send objects 16 bit					
r8747	CO: CAN free PZD receive objects 32 bit					
p8748	CI: CAN free PZD send objects 32 bit					
r8750	CAN mapped receive objects 16 bit					
r8751	CAN mapped receive objects 16 bit					
r8760	CAN mapped receive objects 32 bit					
r8761	CAN mapped transmit objects 32 bit					
r8762	CO: CAN operating mode display					
r8784	CO: CAN status word					
p8785	BI: CAN status word bit 8					

p8786	BI: CAN status word bit 14	r8932	PN Default Gateway of Station active
p8787	BI: CAN status word bit 15	r8933	PN Subnet Mask of Station active
p8790	CAN control word - auto interconnection	r8934	PN DHCP mode active
p8791	CAN holding option code	r8935	PN MAC Address of Station
r8792	CO: CAN Velocity Mode I16 setpoint	r8939	PN DAP ID
r8795	CAN control word	r8960	PN Subslot assignment
r8796	CO: CAN Profile Velocity Mode I32 setpoints	r8961	PN IP Addr Remote Controller 1
r8797	CAN Target Torque	r8962	PN IP Addr Remote Controller 2
p8798	CAN speed conversion factor	p8980	Ethernet/IP profile
	[0] Counters [1] Denominator		0: SINAMICS 1: ODVA / AC/DC
Identification & maintenance data (I&M)		p8981	Ethernet/IP ODVA STOP mode
			0: OFF1 1: OFF2
p8805	Identification and Maintenance 4 configuration	p8982	Ethernet/IP ODVA speed (p8982) or torque (p8983) scaling
	0: Standard value for I&M 4 (p8809)		123: 32 124: 16
	1: User value for I&M 4 (p8809)		125: 8 126: 4
p8806	Identification and Maintenance 1		127: 2 128: 1
	[0...31] Plant ID (PID)		129: 0.5 130: 0.25
	[32...53] Location ID (LID)		131: 0.125 132: 0.0625
p8807	Identification and Maintenance 2		133: 0.03128
	[0...15] YYYY-MM-DD hh.mm	p8991	USB memory access
p8808	Identification and Maintenance 3	Parameter consistency and storage	
	[0...53] Arbitrary supplementary information and remarks (ASCII)	p9400	Safely remove memory card
p8809	Identification and Maintenance 4 (signature)		0 No memory card inserted
PROFIdrive			1 Memory card inserted
r8859	PROFINET identification data		2 Request "safe removal" of the memory card
r8909	PN Device ID		3 "Safe removal" possible
p8920	PN Name of station		100 "Safe removal" not possible due to access
p8921	PN IP Address of Station	r9401	Safely remove memory card status
p8922	PN Default Gateway of Station	r9463	Set valid macro
p8923	PN Subnet Mask of Station	p9484	BICO interconnections, search signal source
p8924	PN DHCP mode	r9485	BICO interconnections, search signal source number
p8925	PN interfaces configuration	r9486	BICO interconnections, search signal source first index
	0: No function	Safety Integrated	
	1: Activate the configuration	p9601	SI enable, functions integrated in the drive (processor 1)
	2: Activate the configuration and save	p9610	SI PROFIsafe address (processor 1)
	3: Delete configuration	p9650	SI F-DI changeover, tolerance time (processor 1) [ms]
p8929	PN Remote Controller number	p9651	SI STO debounce time (processor 1) [ms]
	0: Automation or Safety		
	1: Automation and Safety		
r8930	PN Name of Station active		
r8931	PN IP Address of Station active		

p9659	SI forced checking procedure timer [h]		[1]	Computation time utilization	[5]	Highest gross utilization
r9660	SI forced checking procedure remaining time [h]					
r9670	SI module identifier, Control Unit	p60022	Selecting a PROFIsafe telegram			
r9672	SI module identifier, Power Module	r61000	PROFINET Name of Station			
p9700	SI copy function	r61001	PROFINET IP of Station			
p9701	Acknowledge SI data change					
p9761	SI password input [hex]					
p9762	SI password new [hex]					
p9763	SI password acknowledgment [hex]					
r9768	SI PROFIsafe control words received (processor 1)					
	[0] PZD 1 ...		[7]	PZD 8		
r9769	SI PROFIsafe status words send (processor 1)					
	[0] PZD 1 ...		[7]	PZD 8		
r9770	SI version, safety functions integrated in the drive (processor 1)					
r9771	SI common functions (processor 1)					
r9772	CO/BO: SI status (processor 1)					
r9773	CO/BO: SI status (processor 1 + processor 2)					
r9776	SI diagnostics					
	.00 1 = safety parameters changed, POWER ON required					
	.01 1 = safety functions enabled					
	.02 1 = safety components exchanged and save necessary					
r9780	SI monitoring clock cycle (processor 1) [ms]					
r9781	SI checksum to check changes (processor 1)					
r9782	SI time stamp to check changes (processor 1) [h]					
r9794	SI crosswise comparison list (processor 1)					
r9795	SI diagnostics, STOP F (processor 1)					
r9798	SI actual checksum SI parameters (processor 1)					
p9799	SI reference checksum SI parameters (processor 1)					
p9801	SI enable, functions integrated in the drive (processor 2)					
p9810	SI PROFIsafe address (processor 2)					
p9850	SI F-DI changeover, tolerance time (processor 2)					
p9851	SI STO debounce time (processor 2) [µs]					
r9871	SI common functions (processor 2)					
r9872	CO/BO: SI status (Power Module)					
r9898	SI actual checksum SI parameters (processor 2)					
p9899	SI reference checksum SI parameters (processor 2)					
Diagnostics (internal)						
r9976	System utilization [%]					

Fault rectification

5.1 List of alarms and faults

Axxxxx Alarm

Fyyyyy: Fault

Table 5- 1 The most important alarms and faults of the safety functions

Number	Cause	Remedy
F01600	STOP A Triggered	STO Select and then deselect again.
F01650	Acceptance test required	Carry out acceptance test and create test certificate. Switch the Control Unit off and then on again.
F01659	Write task for parameter rejected	Cause: The converter should be reset to the factory setting. The resetting of the safety functions is, however, not allowed, because the safety functions are currently enabled.
		Remedy with operator panel:
		p0010 = 30 Parameter reset
		p9761 = ... Enter password for the safety functions.
		p0970 = 5 Reset Start Safety Parameter. The converter sets p0970 = 5 if it has reset the parameters.
Then reset the converter to the factory setting again.		
A01666	Static 1 signal at F-DI for safe acknowledgment	F-DI to a logical 0 signal.
A01698	Commissioning mode active for safety functions	This message is withdrawn after the Safety commissioning has ended.
A01699	Shutdown path test required	After the next time that the "STO" function is deselected, the message is withdrawn and the monitoring time is reset.
F30600	STOP A Triggered	STO Select and then deselect again.

Table 5- 2 The most important alarms and faults

Number	Cause	Remedy
F01018	Power-up aborted more than once	1. Switch off the converter power supply and switch it on again. 2. After this fault, the converter powers up with the factory settings. 3. Recommission the converter.
A01028	Configuration error	Explanation: The parameter assignments on the memory card were made with a different type of module (Article No.). Check the module parameters and recommission if necessary.
F01033	Unit switchover: Reference parameter value invalid	Set the value of the reference parameter to a value other than 0.0 (p0304, p0305, p0310, p0596, p2000, p2001, p2002, p2003, r2004).

5.1 List of alarms and faults

Number	Cause	Remedy
F01034	Unit switchover: Calculation of the parameter values after reference value change unsuccessful	Select the value of the reference parameter so that the parameters involved can be calculated in the per unit notation (p0304, p0305, p0310, p0596, p2000, p2001, p2002, p2003, r2004).
F01122	Frequency at the probe input too high	Reduce the frequency of the pulses at the probe input.
A01590	Motor maintenance interval lapsed	Carry out the maintenance.
A01900	PROFIBUS: Configuration telegram faulty	Explanation: A PROFIBUS master is attempting to establish a connection with a faulty configuration telegram. Check the bus configuration on the master and slave side.
A01910 F01910	Fieldbus SS setpoint timeout	The alarm is generated when p2040 ≠ 0 ms and one of the following causes is present: <ul style="list-style-type: none"> • The bus connection is interrupted • The MODBUS master is switched off • Communications error (CRC, parity bit, logical error) An excessively low value for the fieldbus monitoring time (p2040)
A01920	PROFIBUS: Cyclic connection interrupt	Explanation: The cyclic connection to PROFIBUS master is interrupted. Establish the PROFIBUS connection and activate the PROFIBUS master with cyclic operation.
F03505	Analog input, wire break	Check the connection to the signal source for interrupts. Check the level of the signal supplied. The input current measured by the analog input can be read out in r0752.
A03520	Temperature sensor fault	Check that the sensor is connected correctly.
A05000 A05001 A05002 A05004 A05006	Power Module overtemperature	Check the following: <ul style="list-style-type: none"> - Is the ambient temperature within the defined limit values? - Are the load conditions and duty cycle configured accordingly? - Has the cooling failed?
F06310	Supply voltage (p0210) incorrectly parameterized	Check the parameterized supply voltage and if required change (p0210). Check the line voltage.
F07011	Motor overtemperature	Reduce the motor load. Check ambient temperature. Check sensor's wiring and connection.
A07012	I2t Motor Module overtemperature	Check and if necessary reduce the motor load. Check the motor's ambient temperature. Check thermal time constant p0611. Check overtemperature fault threshold p0605.
A07015	Motor temperature sensor alarm	Check that the sensor is connected correctly. Check the parameter assignment (p0601).
F07016	Motor temperature sensor fault	Make sure that the sensor is connected correctly. Check the parameterization (p0601).
F07086 F07088	Unit switchover: Parameter limit violation	Check the adapted parameter values and if required correct.

Number	Cause	Remedy
F07320	Automatic restart aborted	Increase the number of restart attempts (p1211). The current number of start attempts is shown in r1214. Increase the wait time in p1212 and/or monitoring time in p1213. Create ON command (p0840). Increase the monitoring time of the power unit or switch off (p0857). Reduce the wait time for resetting the fault counter p1213[1] so that fewer faults are registered in the time interval.
A07321	Automatic restart active	Explanation: The automatic restart (AR) is active. During voltage recovery and/or when remedying the causes of pending faults, the drive is automatically switched back on.
F07330	Search current measured too low	Increase search current (P1202), check motor connection.
A07400	V _{DC_max} controller active	If the controller is not to intervene: <ul style="list-style-type: none"> • Increase the ramp-down times. • Deactivate the V_{DC_max} controller (p1240 = 0 for vector control, p1280 = 0 for V/f control).
A07409	U/f control current limiting controller active	The alarm automatically disappears after one of the following measures: <ul style="list-style-type: none"> • Increase the current limit (p0640). • Reduce load. • Increase the ramp-up time to the speed setpoint.
F07426	Technology controller actual value limited	<ul style="list-style-type: none"> • Adapt the limits to the signal level (p2267, p2268). • Check the actual value scaling (p2264).
F07801	Motor overcurrent	Check current limits (p0640). U/f control: Check the current limiting controller (p1340 ... p1346). Increase acceleration ramp (p1120) or reduce load. Check motor and motor cables for short circuit and ground fault. Check motor for star-delta connection and rating plate parameterization. Check power unit / motor combination. Select flying restart function (p1200) if switched to rotating motor.
A07805	Drive: Power unit overload I2t	<ul style="list-style-type: none"> • Reduce the continuous load. • Adapt the load cycle. • Check the assignment of rated currents of the motor and power unit.
F07807	Short circuit detected	<ul style="list-style-type: none"> • Check the converter connection on the motor side for any phase-phase short-circuit. • Rule out that line and motor cables have been interchanged.
A07850	External alarm 1	The signal for "external alarm 1" has been triggered. Parameter p2112 defines the signal source of the external alarm. Remedy: Rectify the cause of this alarm.
F07860	External fault 1	Remove the external causes for this fault.
F07900	Motor blocked	<ul style="list-style-type: none"> • Make sure that the motor can rotate freely. • Check the torque limit: r1538 for a positive direction of rotation; r1539 for a negative direction of rotation.

5.1 List of alarms and faults

Number	Cause	Remedy
F07901	Motor overspeed	Activate precontrol of the speed limiting controller (p1401 bit 7 = 1).
F07902	Motor stalled	Check whether the motor data has been parameterized correctly and perform motor identification. Check the current limits (p0640, r0067, r0289). If the current limits are too low, the drive cannot be magnetized. Check whether motor cables are disconnected during operation.
A07903	Motor speed deviation	Increase p2163 and/or p2166. Increase the torque, current and power limits.
A07910	Motor overtemperature	Check the motor load. Check the motor's ambient temperature. Check the KTY84 sensor.
A07920	Torque/speed too low	The torque deviates from the torque/speed envelope curve.
A07921	Torque/speed too high	<ul style="list-style-type: none"> • Check the connection between the motor and the load. • Adapt the parameterization corresponding to the load.
A07922	Torque/speed out of tolerance	
F07923	Torque/speed too low	
F07924	Torque/speed too high	<ul style="list-style-type: none"> • Check the connection between the motor and the load. • Adapt the parameterization corresponding to the load.
A07927	DC braking active	Not required
A07980	Rotary measurement activated	Not required
A07981	No enabling for rotary measurement	Acknowledge pending faults. Establish missing enables (see r00002, r0046).
A07991	Motor data identification activated	Switch on the motor and identify the motor data.
F08501	Setpoint timeout	<ul style="list-style-type: none"> • Check the PROFINET connection. • Set the controller to RUN mode. • If the error occurs repeatedly, check the monitoring time set (p2044).
F08502	Monitoring time, sign-of-life expired	<ul style="list-style-type: none"> • Check the PROFINET connection.
F08510	Send configuration data not valid	<ul style="list-style-type: none"> • Check the PROFINET configuration
A08511	Receive configuration data not valid	
A08526	No cyclic connection	<ul style="list-style-type: none"> • Activate the controller with cyclic operation. • Check the parameters "Name of Station" and "IP of Station" (r61000, r61001).
A08565	Consistency error affecting adjustable parameters	Check the following: <ul style="list-style-type: none"> • IP address, subnet mask or default gateway is not correct. • IP address or station name used twice in the network. • Station name contains invalid characters.

Number	Cause	Remedy
F08700	Communications error	<p>A CAN communications error has occurred. Check the following:</p> <ul style="list-style-type: none"> • Bus cable • Baud rate (p8622) • Bit timing (p8623) • Master <p>Start the CAN controller manually with p8608 = 1 after the cause of the fault has been resolved!</p>
F13100	Know-how protection: Copy protection error	<p>The know-how protection and the copy protection for the memory card are active. An error occurred during checking of the memory card.</p> <ul style="list-style-type: none"> • Insert a suitable memory card and switch the converter supply voltage temporarily off and then on again (POWER ON). • Deactivate the copy protection (p7765).
F13101	Know-how protection: Copy protection cannot be activated	Insert a valid memory card.
F30001	Overcurrent	<p>Check the following:</p> <ul style="list-style-type: none"> • Motor data, if required, carry out commissioning • Motor's connection method (Y / Δ) • U/f operation: Assignment of rated currents of motor and Power Module • Line quality • Make sure that the line commutating reactor is connected properly • Power cable connections • Power cables for short-circuit or ground fault • Power cable length • Line phases <p>If this doesn't help:</p> <ul style="list-style-type: none"> • U/f operation: Increase the acceleration ramp • Reduce the load • Replace the power unit
F30002	DC-link voltage overvoltage	<p>Increase the ramp-down time (p1121). Set the rounding times (p1130, p1136). Activate the DC link voltage controller (p1240, p1280). Check the line voltage (p0210). Check the line phases.</p>
F30003	DC-link voltage undervoltage	Check the line voltage (p0210).
F30004	Converter overtemperature	<p>Check whether the converter fan is running. Check whether the ambient temperature is in the permissible range. Check whether the motor is overloaded. Reduce the pulse frequency.</p>
F30005	I2t converter overload	<p>Check the rated currents of the motor and Power Module. Reduce current limit p0640. When operating with U/f characteristic: Reduce p1341.</p>

5.1 List of alarms and faults

Number	Cause	Remedy
F30011	Line phase failure	Check the converter's input fuses. Check the motor cables.
F30015	Motor cable phase failure	Check the motor cables. Increase the ramp-up or ramp-down time (p1120).
F30021	Ground fault	<ul style="list-style-type: none"> • Check the power cable connections. • Check the motor. • Check the current transformer. • Check the cables and contacts of the brake connection (a wire might be broken).
F30027	Time monitoring for DC link pre-charging	Check the line voltage. Check the line voltage setting (p0210).
F30035	Overtemperature, intake air	<ul style="list-style-type: none"> • Check whether the fan is running. • Check the fan filter elements. • Check whether the ambient temperature is in the permissible range.
F30036	Overtemperature, inside area	
F30037	Rectifier overtemperature	See F30035 and, in addition: <ul style="list-style-type: none"> • Check the motor load. • Check the line phases
A30049	Internal fan defective	Check the internal fan and if required replace.
F30059	Internal fan defective	Check the internal fan and if required replace.
F30074	Communications fault between Control Unit and Power Module	The 24V voltage supply of the converter (terminals 31 and 32) was interrupted briefly. Please check the voltage supply and the wiring.
A30502	DC link overvoltage	<ul style="list-style-type: none"> • Check the device supply voltage (p0210). • Check the line reactor dimensioning
A30920	Temperature sensor fault	Check that the sensor is connected correctly.
A50001	PROFINET configuration error	A PROFINET controller is attempting to establish a connection with a faulty configuration telegram. Check to see whether "Shared Device" is activated (p8929 = 2).
A50010	PROFINET name of station invalid	Correct name of station (p8920) and activate (p8925 = 2).
A50020	PROFINET: Second controller missing	"Shared Device" is activated (p8929 = 2). However, only the connection to a PROFINET controller is present.

For further information, please refer to the List Manual.

5.2 Product support

Table 5-3 Technical Support

France	Germany	Italy	Spain	United Kingdom
+33 (0) 821 801 122	+49 (0)911 895 7222	+39 (02) 24362000	+34 902 237 238	+44 161 446 5545
Further service telephone numbers: Product support (http://www.siemens.com/automation/service&support)				

Table 5-4 Manuals with further information

Information level	Manual	Content	Available languages	Download or article number
+	Compact Operating Instructions	(this manual)	English, German, Italian, French, Spanish, Chinese	Download manuals (http://support.automation.siemens.com/WW/view/en/48213081/133300) SINAMICS Manual Collection Documentation on DVD Article number: 6SL3097-4CA00-0YG0
++	Operating instructions	Installing, commissioning and operating the converter. Description of converter functions. Technical data.	English, German, Italian, French, Spanish, Chinese	
+++	Function Manual Safety Integrated	Configuring PROFIsafe. Installing, commissioning and operating the integrated fail-safe function.	English, German	
+++	List manual	Complete list of parameters, alarms and faults. Graphic function block diagrams.	English, German, Chinese	
+++	Operating instructions - BOP-2, IOP	Description of operator panel	English, German	

5.3 Spare parts

	Article number	
5 sets of I/O terminals, 1 set of front doors and 1 piece operator panel blind cover	6SL3200-0SK41-0AA0	
Screening plates including mounting accessories	Frame size AA	6SL3266-1ER00-0KA0
	Frame size A	6SL3266-1EA00-0KA0
	Frame size B	6SL3266-1EB00-0KA0
	Frame size C	6SL3266-1EC00-0KA0
1 set of connector plugs for mains, motor and breaking resistor	Frame size AA, A	6SL3200-0ST05-0AA0
	Frame size B	6SL3200-0ST06-0AA0
	Frame size C	6SL3200-0ST07-0AA0
Fan unit for the heat sink, consists of plugable frame with built in fan	Frame size A	6SL3200-0SF12-0AA0
	Frame size B	6SL3200-0SF13-0AA0
	Frame size C	6SL3200-0SF14-0AA0
Top fan, consists of top cover with built in fan	Frame size AA	6SL3200-0SF38-0AA0
	Frame size A	6SL3200-0SF40-0AA0
	Frame size B	6SL3200-0SF41-0AA0
	Frame size C	6SL3200-0SF42-0AA0

SINAMICS G120C DOCUMENTATION PACK



Printed in the United Kingdom

Further information

SINAMICS inverters:
www.siemens.com/sinamics

Safety Integrated:
www.siemens.com/safety-integrated

PROFINET:
www.siemens.com/profinet

Siemens AG
Digital Factory
Motion Control
Postfach 3180
91050 ERLANGEN
GERMANY

Subject to change without prior notice
© Siemens AG 2011-2015

For additional
information on
SINAMICS G120,
scan the QR code.

